



ALL-SG8205PDM

5 Port Gigabit Managed Fanless PoE (1 Port PD) Switch



USER MANUAL

Table of Content

Package Contents.....	4
1. Introduction	4
2. Hardware Description	4
2.1 Front Panel	4
2.2 Rear Panel.....	5
3. Installation the Switch	5
3.1 Desktop Installation	6
3.2 Wall-mountable Installation.....	6
3.3 Turn on the switch	7
4. How to Login the Switch	7
4.1 Switch to End Node.....	7
4.2 Logging on the Switch.....	7
5. Management the Switch	9
5.1 Administrator.....	9
5.1.1 System Information.....	9
5.1.2 User Config	9
5.1.3 Management File	10
5.1.4 Access config.....	11
5.1.5 SNMP Config.....	12
5.2 Interface Manage.....	13
5.2.1 Storm control.....	13
5.2.2 port rate-limit.....	14
5.2.3 Mirror	14
5.2.4 Port channel Config	15
5.2.5 Isolate-port config.....	17
5.2.6 Port statistics.....	17
5.2.7 PoE Config.....	19
5.3 Business manage.....	21
5.3.1 VLAN config.....	21
5.3.2 MAC Config	23
5.3.3 Spanning-tree config	26
5.3.4 IGMP-SNOOPING	28
5.3.5 Qinq-cofig.....	30
5.3.6 Qos Config	30
5.3.7 LLDP Config	31
5.3.8 DHCP Server Config.....	33
5.3.9 Time Range Config.....	35
5.4 Route Manage	36
5.4.1 L3 interface set up.....	36
5.4.2 show route.....	36
5.4.3 Static Config	36

5.5 Network Security	37
5.5.1 Access Control.....	37
5.5.2 Attack protection	37
5.5.3 ACL Config	37
5.5.4 Traffic monitor.....	38
5.5.5 Alarm-config.....	39
5.6 System management.....	40
5.6.1 Log Config.....	40
5.6.2 Diagnosis.....	40
5.6.3 NTP Config	41
5.6.4 Reboot.....	41
5.6.5 Firmware	42
5.7 Save.....	43
5.8 Hardware Specifications.....	44

Package Contents

Check the following contents of your package:

- ALL-SG8205PDM x 1
- User Manual x 1
- Accessories(Rubber Feet x4)

If any part is lost and damaged, please contact your local agent immediately.

1. Introduction


The ALL-SG8205PDM provide wire-speed performance and abundant layer 2 management features. It provides a variety of service features and multiple powerful functions with high security. They also Power Sourcing Equipment. All the 10/100/1000Mbps RJ45 ports on the switch support Power over Ethernet function, which can automatically detect and supply power with those powered devices complying with IEEE 802.3af and IEEE 802.3at.

The ALL-SG8205PDM integrates multiple functions with excellent performance, and is friendly to manage, which can fully meet the need of the users demanding higher networking performance. include Administrator, PoE, Port Management, VLAN Setting, QoS Setting, Security, Spanning Tree, Trunking, DHCP Relay Agent, Backup/Recovery, SNMP settings and so on.

2. Hardware Description

2.1 Front Panel

The Front Panel Consists 4-Port Gigabit+1GE (PD) +1Console Managed PoE Switch. The LED indicators and Reset Button also on located on the panel.




LED indicator

LED	Color	Function
PWR	Green	Off: No Power supply Light: Indicates the switch has power
LNK/ACT	Green	Off: No device is connected to the corresponding port Light: Indicates the link through that port is successfully established at 10/100/1000Mbps. Blink: Indicates that the Switch is actively sending or receiving data over that port.
SYS	Green	Blinking: the system works Out: the system is starting or has no power
PoE	Orange	Off: No PoE powered device (PD) connected Light: There is a PoE PD connected to be port, which supply power successfully. Blink: Indicates port abnormal power supply
Fault	Green	Off: the equipment is connected to normal Light: unit exception

2.2 Rear Panel

The rear panel indicates an DC inlet power socket, Grounding Column.



3. Installation of the Switch

This part describes how to install your ALL-SG8205PDM and make connections to it. Please follow the following instructions in avoid of incorrect installation causing device damage and security threat.


- Before cleaning the switch, unplug the power plug of the switch first. Do not clean the switch with wet cloth or liquid;
- Do not place the switch near water or any damp area. Prevent water or moisture from entering

the switch chassis;

- Do not place the switch on an unstable case or desk. The switch might be damaged severely in case of a fall;
- Ensure proper ventilation of the equipment room and keep the ventilation vents of the switch free of obstruction;
- Make sure that the operating voltage is the same one labeled on the switch;
- Do not open the chassis while the switch is operating or when electrical hazards are present to avoid electrical shocks.

3.1 Desktop Installation


Install the Switch on a desktop, please attach these cushioning rubber feet provided on the bottom at each corner of the Switch in case of the external vibration. Allow adequate space for ventilation between the device and the objects around it.



3.2 Wall-mountable Installation

In the first two fixed screw on the wall as shown in the figure below

Aim at the two fixed hole switches, and the machine smoothly on the screw



3.3 Turn on the switch


The PoE switch can be used with DC power supply. Powering on the switch, it will automatically initialize and its LED indicators will respond as follows:

- 1) Firstly, the Power LED indicator will light up.
- 2) Then, the data LED indicators will flash momentarily for one second, which represents a resetting of the system.

4. How to Login the Switch

4.1 Switch to End Node

Use standard Cat.5/5e Ethernet cable (UTP/STP) to connect the Switch to end nodes as described below. The ALL-SG8205PDM ports will automatically adjust to the characteristics (MDI/MDI-X, speed, duplex) of the device to which is connected.



Please refer to the LED Indicator Specification. The Link/Act LED for each port lights green when the link is available.

4.2 Logging on the Switch

As the ALL-SG8205PDM provides Web-based management login, you can configure your computer's IP address manually to log on to the ALL-SG8205PDM. The default settings of the ALL-SG8205PDM are shown below.

Parameter	Default Value
Default IP address	192.168.2.1
Default user name	admin
Default password	admin

You can log on to the welcome window of the the ALL-SG8205PDM through following steps:


1. Connect the ALL-SG8205PDM with the computer NIC interface.
2. Power on the ALL-SG8205PDM.
3. Check whether the IP address of the computer is within this network segment: 192.168.2.xxx ("xxx" ranges 0~255), for example, 192.168.2.100.

4. Open the browser, and enter <http://192.168.2.1> and then press “Enter”. The ALL-SG8205PDM login window appears, as shown below.



The image shows the login interface for the ALLNET ALL-SG8205PDM switch. At the top is the ALLNET logo and the model name. Below it is a 'USER LOGIN' heading with a user icon. A prompt asks the user to input their username and password. There are two input fields: 'User' with the text 'admin' and 'Passwd' with masked characters. Below the fields are 'Login' and 'Reset' buttons.

5. Enter the user name and password (The factory default login username and password is admin), and then click “Login” to log in to the Switch configuration window as below.



The image shows the main configuration window of the ALLNET switch. The top header bar contains the ALLNET logo, the device description '5 Port Gigabit PoE Powered (PD) Managed Switch', the model 'ALL-SG8205PDM', and a 'Logout' link. A left sidebar lists various management categories. The main area is divided into a 'Device information' section on the left and a resource usage chart on the right. The 'Device information' section lists details like device model, name, software version, MAC address, running time, time zone, device time, CPU usage, and memory usage. The resource usage chart shows CPU at 0% and MEMORY at 84%.

Device information	
Device model	ALL-SG8205PDM
Device name	switch
Software version	2.3.1 build 403
CPU MAC	00:00:11:11:22:33
Running time	0Day, 0 Hours, 18 Minutes
Time Zone	UTC+01:00
Device Time	1:1:2000 8:19:31 Change Time
CPU usage	0.5%
Memory usage	84% (free:9864 KB, total:60420 KB)
Temperature	

Apply Refresh


CPU: 0%
MEMORY: 84%

5. Management the Switch

5.1 Administrator

5.1.1 System Information


This page is used to check the status of ALL-SG8205PDM, including Switch MAC address and software version.



The MAC address and version of the switch will be shown at system status diagram box. Comment field can accept "Aa~Zz", "0-9", "_", "+", "-", "=", excluding special character.

5.1.2 User Config

This page shows system configuration including the current user name and password and privilege.



5.1.3 Management File

This page shows system configuration including the current running-config, the start configuration, management file

Running-config is the currently running configuration

The start configuration is the state of preservation before the last outage

The screenshot displays the ALLNET web management interface for a 5 Port Gigabit PoE Powered (PD) Managed Switch (ALL-SG8205PDM). The interface has a blue header with the ALLNET logo, the device name, and a Logout button. A left sidebar contains a menu with options: System Manage, System Information, User Config, Management File (highlighted), Access Config, SNMP Config, Interface Manage, Business Manage, Route Manage, Network security, System manage, and Save. The main content area has three tabs: RUNNING-CONFIG (selected), THE START CONFIGURATION, and MANAGEMENT FILE. The RUNNING-CONFIG tab shows the following configuration:

```
Running-config
version 2.3.1 build 403
ip http-server all
ip http-server language en
timezone utc plus 1
!
username admin password gRUaAGaRgINK6
!
interface gel/1
!
interface gel/2
!
interface gel/3
!
interface gel/4
!
interface gel/5
!
interface vlanif1
ip address 192.168.2.1/24
!
line vty
!
```

At the bottom of the configuration area, there is a 'Save' button and a note: '(Save the current configuration to the startup file)'.

The start configuration is the state of preservation before the last outage

ALLNET® 5 Port Gigabit PoE Powered (PD) Managed Switch ALL-SG8205PDM Logout

RUNNING-CONFIG THE START CONFIGURATION MANAGEMENT FILE

The Start configuration

```
ip http-server all
ip http-server language en
timezone utc plus 1
!
username admin password gRUaAGaRgINK6
!
vlan 1
!
interface ge1/1
!
interface vlanif1
ip address 192.168.2.1/24
!
line vty
!
```

Restore (Take effect after reboot) Download

Management File is the Upload profile

ALLNET® 5 Port Gigabit PoE Powered (PD) Managed Switch ALL-SG8205PDM Logout


RUNNING-CONFIG THE START CONFIGURATION MANAGEMENT FILE

File path Keine C

Take effect after reboot

5.1.4 Access config

Access configuration can configure http,telnet,and SSH


5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
System Information
User Config
Management File
Access Config
SNMP Config
Interface Manage
Business Manage
Route Manage
Network security
System manage

Save

HTTP-config
HTTP Service ☒ Enable
HTTPS Service ☒ Enable
Port 80 Default is 80, Modify default port, need specify port number at web browsers


Telnet-config
Telnet Service ☐
Port 23

SSH-config
SSHSservice ☐
Port 22

Apply Cancel

5.1.5 SNMP Config

This page contains SNMP-config、V3-config、trapconfig



5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
System Information
User Config
Management File
Access Config
SNMP Config
Interface Manage
Business Manage
Route Manage
Network security
System manage

Save

SNMP-config
Mode ☐ Enable ☒ Disable
Version v1,v2c,v3
Name switch
Description cns-2.3.1
Location Germany
Contact x@x
Engine no.
Apply Cancel

• SNMP user -config
• SNMP Trap -config


5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
System Information
User Config
Management File
Access Config
SNMP Config
Interface Manage
Business Manage
Route Manage
Network security
System manage

Save

SNMP v3-config
Name
Authentication md5
Privacy des
Apply Return

5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
System Information
User Config
Management File
Access Config
SNMP Config
Interface Manage
Business Manage
Route Manage
Network security
System manage
Save

SNMP Trap-config

Events
☐ Coldstart&Warmstart
☐ LinkChange
☐ Traffic overload
☐ User Login/logout
☐ User operation
☐ Mac Learning

Version
v1

Trap host

Apply
Return

5.2 Interface Manage

5.2.1 Storm control

Storm control allows ports to filter certain types of storm messages that appear on the network. After the storm control is turned on, when the corresponding frame received by the port accumulates to a predetermined limit, the port will automatically discard the received data frame. Avoid network congestion caused by port storms.

Broadcast Storm print, only configure storm suppression only fill in storm suppression value, and select the corresponding port, other storm suppression does not need to set the value to 0.

5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Port Management
Storm control
Port rate-Limit
Mirror
Port channel Config
Isolate-port Config
Port statistics
POE-config
Business Manage
Route Manage
Network security
System manage
Save

Port
☐ ge1/1
☐ ge1/2
☐ ge1/3
☐ ge1/4
☐ ge1/5
Select All

Broadcast
Unkown-Multicast
DLF

units:kbps, Rate of 0 disables rate limiting , scope:0-1000000

Apply

Port	Broadcast	Unkown-Multicast	DLF
Refresh			

5.2.2 port rate-limit

Configuring port rate can limit the bandwidth of a port and avoid overflowing a port with too many data packets. Configuration burst and entry rate are configured together to take effect.

The screenshot shows the ALLNET web interface for a 5 Port Gigabit PoE Powered (PD) Managed Switch (ALL-SG8205PDM). The left sidebar contains a menu with options: System Manage, Interface Manage, Port Management, Storm control, Port rate-Limit (selected), Mirror, Port channel Config, Isolate-port Config, Port statistics, POE-config, Business Manage, Route Manage, Network security, System manage, and Save. The main content area is titled 'Port rate-Limit'. It features a 'Port' selection bar with checkboxes for ge1/1, ge1/2, ge1/3, ge1/4, ge1/5, and a 'Select All' link. Below this are input fields for 'InputRate', 'Burst', 'OutputRate', and 'Burst', followed by an 'Apply' button. A note indicates 'unit:kbps, Rate Rate of 0 disables rate limiting , scope:0-1000000'. At the bottom, there is a table with headers: Port, InputRate, InputBurst, OutputRate, and OutputBurst, and a 'Refresh' button.

5.2.3 Mirror

A message sent or received by a port can be copied to the monitoring port. Mirroring is based on vlan, the default port belongs to Vlan1, testing needs to send vlan tagged data message. There are four session IDs, and different IDs can set up different mirroring groups.

The screenshot shows the ALLNET web interface for a 5 Port Gigabit PoE Powered (PD) Managed Switch (ALL-SG8205PDM). The left sidebar contains a menu with options: System Manage, Interface Manage, Port Management, Storm control, Port rate-Limit, Mirror (selected), Port channel Config, Isolate-port Config, Port statistics, POE-config, Business Manage, Route Manage, Network security, System manage, and Save. The main content area is titled 'Mirror'. It features a 'SessionID' dropdown menu set to '1'. Below this are input fields for 'SourcePort' (with checkboxes for ge1/1, ge1/2, ge1/3, ge1/4, ge1/5, and a 'Select All' link), 'Destination port' (a dropdown menu set to 'ge1/1'), and 'Direction' (a dropdown menu set to 'both'). An 'Add' button is located below these fields. At the bottom, there is a table with headers: SessionID, SourcePort, Destination port, and Direction, and a 'Refresh' button.

5.2.4 Port channel Config

This page contains STATIC LINK-AGGR、PORT CONFIG、LACP、LACPSTATUS、LACPSTATISTICS

ALLNET®

5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Port Management

Storm control

Port rate-Limit

Mirror

Port channel Config

Isolate-port Config

Port statistics

POE-config

Business Manage

Route Manage

Network security

System manage

Save

STATIC LINK-AGGR

PORT CONFIG

LACP

LACPSTATUS

LACPSTATISTICS

Group ID

1

Load balance mode

Src Mac

Port list

ge1/1

ge1/2

ge1/3

ge1/4

ge1/5

Select All

Add

Delete

Group ID	Type	Status	Load balance mode	Port member
Refresh				

PORT CONFIG

ALLNET®

5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Port Management

Storm control

Port rate-Limit

Mirror

Port channel Config

Isolate-port Config

Port statistics

POE-config

Business Manage

Route Manage

Network security

System manage

Save

STATIC LINK-AGGR

PORT CONFIG

LACP


LACPSTATUS

LACPSTATISTICS

PortName	Type	Group ID	Mode	Key	timeout	PortPriority
ge1/1	None	1	Active	0	Fast	32768
ge1/2	None	1	Active	0	Fast	32768
ge1/3	None	1	Active	0	Fast	32768
ge1/4	None	1	Active	0	Fast	32768
ge1/5	None	1	Active	0	Fast	32768

ApplyCancel

LACP



5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage
Interface Manage
Port Management
Storm control
Port rate-Limit
Mirror
Port channel Config
Isolate-port Config
Port statistics
POE-config
Business Manage
Route Manage
Network security
System manage
Save


STATIC LINK-AGGR
PORT CONFIG
LACP
LACPSTATUS
LACPSTATISTICS

System priority scope:0-65535
Load balance mode Port selection criteria

Apply Cancel

Group ID	PartnerSystemID	PartnerKey	PartnerPrio	LastChanged	LocalPorts
Refresh					

LACPSTATUS



5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage
Interface Manage
Port Management
Storm control
Port rate-Limit
Mirror
Port channel Config
Isolate-port Config
Port statistics
POE-config
Business Manage
Route Manage
Network security
System manage
Save

STATIC LINK-AGGR
PORT CONFIG
LACP
LACPSTATUS
LACPSTATISTICS

Flags:
A -- LACP_Activity, B -- LACP_timeout, C -- Aggregation, D -- Synchronization, E -- Collecting, F -- Distributing, G -- Defaulted, H -- Expired

PortName	Key	Flags	Aggid	PartnerSystemID	PartnerPort	PartnerPrio
Refresh						

LACPSTATISTICS

5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Port Management
Storm control
Port rate-Limit
Mirror
Port channel Config
Isolate-port Config
Port statistics
POE-config
Business Manage
Route Manage
Network security
System manage
Save

STATIC LINK-AGGR
PORT CONFIG
LACP
LACPSTATUS
LACPSTATISTICS

PortName	Receive	Transmit	Unknown	Error
Refresh				

5.2.5 Isolate-port config

Port isolation can realize the independence of receiving and sending ports. It is convenient to designate a port to receive messages from a particular port and discard messages from some ports.

5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Port Management
Storm control
Port rate-Limit
Mirror
Port channel Config
Isolate-port Config
Port statistics
POE-config
Business Manage
Route Manage
Network security
System manage
Save

Isolate-port Config

Input port
ge1/1

Output port
☐ ge1/1
☐ ge1/2
☐ ge1/3
☐ ge1/4
☐ ge1/5
Select All

The packets from in port can't forward to selected out-ports
Add

Input port	Output port
Refresh	

5.2.6 Port statistics

Port stats

The data message received or sent by the current port can be analyzed for each port. Port statistics are divided into port summary statistics and port detailed statistics. You need to analyze different messages in detail, and you can see the port details.



System Manage

Interface Manage

Port Management

Storm control

Port rate-Limit

Mirror

Port channel Config

Isolate-port Config

Port statistics

POE-config

Business Manage

Route Manage

Network security

System manage

Save

PORT STATS

DETAIL PORT STATS

RATE

PortName	ReceivePacket num	SendPacket num	ReceiveByte num	SendByte num	DropPacket num
ge1/1	0	0	0	0	0
ge1/2	0	0	0	0	0
ge1/3	0	0	0	0	0
ge1/4	0	0	0	0	0
ge1/5	12282	3468	999604	1379354	0

Clear

Refresh



System Manage

Interface Manage

Port Management

Storm control

Port rate-Limit

Mirror

Port channel Config

Isolate-port Config

Port statistics

POE-config

Business Manage

Route Manage

Network security

System manage

Save

PORT STATS

DETAIL PORT STATS

RATE

Port: ge1/1

Refresh

Clear

ReceiveTotal		SendTotal	
ReceivePacket num	0	SendPacket num	0
ReceiveByte num	0	SendByte num	0
ReceiveUnicast num	0	SendUnicast num	0
ReceiveMulticast num	0	SendMulticast num	0
ReceiveBroadcast num	0	SendBroadcast num	0
ReceivePause frame	0	SendPause frame	0
ReceiveDiscard	0	SendDiscard	0
ReceiveFCS errors	0		
ReceiveOversize	0		
ReceiveAlignment errors	0		
ReceiveMessage size classification statistics		SendMessage size classification statistics	
Receive64Byte size packet num	0	Send64Byte size packet num	0
Receive65-127Byte size packet num	0	Send65-127Byte size packet num	0
Receive128-255Byte size packet num	0	Send128-255Byte size packet num	0
Receive256-511Byte size packet num	0	Send256-511Byte size packet num	0
Receive512-1023Byte size packet num	0	Send512-1023Byte size packet num	0
Receive1024-1518Byte size packet num	0	Send1024-1518Byte size packet num	0
Receive1519-2047Byte size packet num	0	Send1519-2047Byte size packet num	0
Receive2048-4095Byte size packet num	0	Send2048-4095Byte size packet num	0
Receive4096-9216Byte size packet num	0	Send4096-9216Byte size packet num	0

System Manage

Interface Manage

Port Management

Storm control

Port rate-Limit

Mirror

Port channel Config

Isolate-port Config

Port statistics

POE-config

Business Manage

Route Manage

Network security

System manage

Save

PORT STATS

DETAIL PORT STATS

RATE

IQD: pkts dropped from input queue; OQD: pkts dropped from output queue;


RXBS: rx rate; RXPS: rx rate; TXBS: tx rate; TXPS: tx rate

PortName	IQD(pkts/sec)	OQD(pkts/sec)	RXBS(bits/sec)	RXPS(pkts/sec)	TXBS(bits/sec)	TXPS(pkts/sec)
ge1/1	0	0	0	0	0	0
ge1/2	0	0	0	0	0	0
ge1/3	0	0	0	0	0	0
ge1/4	0	0	0	0	0	0
ge1/5	0	0	841	7	1030	3

Refresh

5.2.7 PoE Config

This page contains port config、Global config、schedule



5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Port Management

Storm control

Port rate-Limit

Mirror

Port channel Config

Isolate-port Config

Port statistics

POE-config

Business Manage

Route Manage

Network security

System manage

Save


PORT CONFIG GLOBAL CONFIG SCHEDULE

PortName	Status	Enable	Current Power(W)	Current Vol(mV)	Current(mA)	Max curr(mA)	Classification
*		*				*	
ge1/1	Disconnect	<input checked="" type="checkbox"/>	-	-	-	374	-
ge1/2	Disconnect	<input checked="" type="checkbox"/>	-	-	-	374	-
ge1/3	Disconnect	<input checked="" type="checkbox"/>	-	-	-	374	-
ge1/4	Disconnect	<input checked="" type="checkbox"/>	-	-	-	374	-

Apply

Refresh

Global config



5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Port Management

Storm control

Port rate-Limit

Mirror

Port channel Config

Isolate-port Config

Port statistics

POE-config

Business Manage

Route Manage

Network security

System manage

Save

PORT CONFIG GLOBAL CONFIG SCHEDULE

Input Vol(mV)

56248


Temperature(C)

4294947

Apply

Refresh

Schedule



5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage
Interface Manage
Port Management
Storm control
Port rate-Limit
Mirror
Port channel Config
Isolate-port Config
Port statistics
POE-config
Business Manage
Route Manage
Network security
System manage

Save

PORT CONFIG GLOBAL CONFIG SCHEDULE


PortName	TimeRange
*	
ge1/1	
ge1/2	
ge1/3	
ge1/4	

Apply
Refresh

5.3 Business manage

5.3.1 VLAN config

This page contains port config、VLANAPPLY、MAC-VLANAPPLY、PROTOCOL-VLANAPPLY



5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage

Save

PORT CONFIG VLANAPPLY MAC-VLANAPPLY PROTOCOL-VLANAPPLY

Pvlan is default vlan. default is 1.
Discard: none-not dicard; untag-discard untag packet; tag-discard tag packet; all-discard all packet.
Filter: Modes for VLAN ingress/egress filtering.

Port	Pvlan	InputDrop	Filter
*	*	*	*
ge1/1	1	None	Egress
ge1/2	1	None	Egress
ge1/3	1	None	Egress
ge1/4	1	None	Egress
ge1/5	1	None	Egress

Apply
Cancel

VLAN APPLY

5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

PORT CONFIGVLANAPPLYMAC-VLANAPPLYPROTOCOL-VLANAPPLY

Vlan ID
scope:1-4094,
Multicast
Flood-unknown

☒ Untag
☐ Tag
☐ ge1/1
☐ ge1/2
☐ ge1/3
☐ ge1/4
☐ ge1/5
Select All

Add
Delete

VID	Description	Multicast	Port list
1		flood-unknown	Untag: Tag: Pvlan: ge1/1 ge1/2 ge1/3 ge1/4 ge1/5

Total 1 Entry
20 entrys per page
1/1Page
Go

MAC-VLAN APPLY

5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

PORT CONFIGVLANAPPLYMAC-VLANAPPLYPROTOCOL-VLANAPPLY

Vlan based on
Vlan ID
scope:1-4094, The ports must belong to the vlan in untag mode
MAC
eg:00:01:02:03:04:05

Add

SerialNum	Vlan ID	MAC
-----------	---------	-----

Total 0 Entry
20 entrys per page
1/1Page
Go

PROTOCOL-VLANAPPLY

© ALLNET GmbH Computersysteme 2018 - Alle Rechte vorbehalten

Irrtum und Änderungen vorbehalten

22

5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

PORT CONFIGVLANAPPLYMAC-VLANAPPLYPROTOCOL-VLANAPPLY

Portge1/1
Frame-typeether2
Ether-typearp
Vlan ID
scope:1-4094. The ports must belong to the vlan in untag mode
Add

SerialNumPortFrame-typeEther-typeVlan ID

Total 0 Entry20 entrys per page
1/1Page
Go

5.3.2 MAC Config

The default is dynamic mac. you can modify the mac aging time

This page contains MACUST、STATIC MAC、MAC-CONFIG

5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

MACLISTSTATIC MACMAC-CONFIG

Clearma

SerialNum	MAC	Vid	Interface	Type
1	00:08:54:56:7e:fa	1	ge1/5	dynamic
2	f0:9fc2:09:b6:83	1	ge1/5	dynamic
3	00:0fc9:08:dde3	1	ge1/5	dynamic
4	f0:9fc2:09:b6:82	1	ge1/5	dynamic


Total 4 Entry20 entrys per page
1/1Page
Go

STATIC MAC

© ALLNET GmbH Computersysteme 2018 - Alle Rechte vorbehalten

Irrtum und Änderungen vorbehalten

23



5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage

Save

MACLIST STATIC MAC **MAC-CONFIG**

MAC bind

MAC

eg:00:01:02:03:04:05 or 0000-0000-0001

Vlan ID

scope:1-4094

Port

ge1/1


eg:ge1/1

Add

SerialNum	MAC	Vlan ID	Port
Total 0 Entry 20 entrys per page			

1/1Page Go

MAC-CONFIG



5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage

Save

MACLIST STATIC MAC **MAC-CONFIG**


MAC address aging-time

300

Apply

scope:10-1000000 , Default:300 , unit: Seconds

Mac limit
• MAC limit(port)
• MAC limit(vlan)



5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM


Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

MACLIST STATIC MAC **MAC-CONFIG**

Port	Enable	mac-limit	Action
*	*	*	*
ge1/1	<input type="checkbox"/>	8190	broadcast
ge1/2	<input type="checkbox"/>	8190	broadcast
ge1/3	<input type="checkbox"/>	8190	broadcast
ge1/4	<input type="checkbox"/>	8190	broadcast
ge1/5	<input type="checkbox"/>	8190	broadcast

Apply
Return



5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

Vlan Id scope:1-4094
Limit count scope:0-16383, default is 16383
Action broadcast
Add Return
MAC limit

SerialNum VlanId Limit Action

Total 0 Entry 20 entrys per page

1/1Page
Go

5.3.3 Spanning-tree config

This page contains GLOBAL CONFIG 、PORT CONFIG、INSTANCE CONFIG

ALLNET®

5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Business Manage

VLAN Config

MAC Config

Spanning-tree Config

ERPS-Ring Config

L2 mcast-config

QINQ-config

QOS Config

LLDP Config

DHCP Server Config

Time Range Config

Route Manage

Network security

System manage

Save

GLOBAL CONFIG

PORT CONFIG

INSTANCE CONFIG

INST-PORT CONFIG

EnableSpanning-tree☒

Mode

☐stp☐rstp☒mstp

Priority

32768

scope:0-61440, Default:32768

Max age

20

scope:6-40, Default:20

Hello time

2

scope:1-10, Default:2

Forward delay

15

scope:4-30, Default:15

Max hop

20

scope:1-40, Default:20

Revision

0

scope:0-65535

Name

000011112233

Apply

Cancel

PORT CONFIG

ALLNET®

5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Business Manage

VLAN Config

MAC Config

Spanning-tree Config

ERPS-Ring Config

L2 mcast-config

QINQ-config

QOS Config

LLDP Config

DHCP Server Config

Time Range Config

Route Manage

Network security

System manage

Save

GLOBAL CONFIG

PORT CONFIG

INSTANCE CONFIG

INST-PORT CONFIG

Port	Enable	BPDU Guard	Edge	Point-to-Point
*	<div>*</div>	<div>*</div>	<div>*</div>	<div>*</div>
ge1/1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Auto	Auto
ge1/2	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Auto	Auto
ge1/3	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Auto	Auto
ge1/4	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Auto	Auto
ge1/5	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Auto	Auto

Apply

Cancel

INSTANCE CONFIG

5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

GLOBAL CONFIG PORT CONFIG INSTANCE CONFIG INST-PORT CONFIG

MSTID 1
Priority 32768
Vlan Mapped separated by ',' '-' is scope,such as 2,4-7,9,10-15
Add

Instance	Priority	Vlan Mapped
0	32768	1-4094

Refresh

INST-PORT CONFIG

5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

GLOBAL CONFIG PORT CONFIG INSTANCE CONFIG INST-PORT CONFIG

MSTID: 0 Refresh

Port	Enable	Instance	Priority	AdminCost	Cost	Role	Status
*			*	*			
ge1/1	Yes	0	128	0	200000000	Disabled	-
ge1/2	Yes	0	128	0	200000000	Disabled	-
ge1/3	Yes	0	128	0	200000000	Disabled	-
ge1/4	Yes	0	128	0	200000000	Disabled	-
ge1/5	Yes	0	128	0	20000	Designated	forwarding

Apply Cancel

5.3.4 IGMP-SNOOPING

This page contains IGMP-SNOOPING、GROUPAPPLY、VLANAPPLY、STATIC MULTICAST

ALLNET®

5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Business Manage

VLAN Config

MAC Config

Spanning-tree Config

ERPS-Ring Config

L2 mcast-config

QINQ-config

QOS Config

LLDP Config

DHCP Server Config

Time Range Config

Route Manage

Network security

System manage

Save

IGMP-SNOOPING CONFIG

STATIC IP MULTICAST

MCASTAPPLY

Enable Igmp-snooping

Send query

Host age-time

260

scope:200-1000, Default:260

Apply

Cancel

Vlan-config

Igmp-snooping groupList

GROUP APPLY

ALLNET®

5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Business Manage

VLAN Config

MAC Config

Spanning-tree Config

ERPS-Ring Config

L2 mcast-config

QINQ-config

QOS Config

LLDP Config

DHCP Server Config

Time Range Config

Route Manage

Network security

System manage

Save

IGMP-SNOOPING CONFIG

STATIC IP MULTICAST

MCASTAPPLY

Clear

Return

SerialNum	Vlan ID	Multicast source	Multicast addr	Port list(Expire)
Total 0 Entry 20 entrys per page				

1/1Page

Go

Refresh

VLAN APPLY

5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

IGMP-SNOOPING CONFIG STATIC IP MULTICAST MCASTAPPLY

Vlan ID
scope:1-4094
Multicast source
eg:192.168.1.1if empty(0.0.0.0),any source
Multicast addr
eg:225.1.2.3
Port list
☐ ge1/1 ☐ ge1/2 ☐ ge1/3 ☐ ge1/4 ☐ ge1/5 [Select All](#)
Add

SerialNum	Vlan ID	Multicast source	Multicast addr	Port list
Total 0 Entry 20 entrys per page				

1/1Page Go

STATIC MULTICAST

5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

IGMP-SNOOPING CONFIG STATIC IP MULTICAST MCASTAPPLY

Vlan ID
scope:1-4094
Multicast source
eg:192.168.1.1if empty(0.0.0.0),any source
Multicast addr
eg:225.1.2.3
Port list
☐ ge1/1 ☐ ge1/2 ☐ ge1/3 ☐ ge1/4 ☐ ge1/5 [Select All](#)
Add

SerialNum	Vlan ID	Multicast source	Multicast addr	Port list
Total 0 Entry 20 entrys per page				

1/1Page Go

MCASTAPPLY

ALLNET®

5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Business Manage

VLAN Config

MAC Config

Spanning-tree Config

ERPS-Ring Config

L2 mcast-config

QINQ-config

QOS Config

LLDP Config

DHCP Server Config

Time Range Config

Route Manage

Network security

System manage

Save

IGMP-SNOOPING CONFIG

STATIC IP MULTICAST

MCASTAPPLY

Vlan ID

scope:1-4094

MAC

eg:01:01:02:03:04:05 or 0100-0000-0001

Port list

☐ ge1/1

☐ ge1/2

☐ ge1/3

☐ ge1/4

☐ ge1/5

Select All

Add

SerialNum	Vlan ID	MAC	Port list
Total 0 Entry 20 entrys per page			

1/1Page << < > >> Go >>>

5.3.5 Qinq-cofig

ALLNET®

5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Business Manage

VLAN Config

MAC Config

Spanning-tree Config

ERPS-Ring Config

L2 mcast-config

QINQ-config

QOS Config

LLDP Config

DHCP Server Config

Time Range Config

Route Manage

Network security

System manage

Save

Port	Mode	ACTION	TPID
*	*	*	*
ge1/1	None	None	0x8100
ge1/2	None	None	0x8100
ge1/3	None	None	0x8100
ge1/4	None	None	0x8100
ge1/5	None	None	0x8100

Apply Cancel

5.3.6 Qos Config

This page contains GLOBAL CONFIG、PORT CONFIG

5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

GLOBAL CONFIGPORT CONFIG

Policy
☒ SP
☐ WRR
☐ DRR
Apply

Weight
W0:
W1:
W2:
W3:

Set up class-of-service policy and corresponding weights and delay

COSCos map queue
COS
0
-> Queue
0
Apply

Map packet to special queue according to cos.

Current map
0->0
1->0
2->1
3->1
4->2
5->2
6->3
7->3

DSCPCos map queue
DSCP
0
-> New DSCP
0
-> COS
0
Apply

Define a mapping for diffserv code points

Current map

PORT CONFIG

5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save


GLOBAL CONFIGPORT CONFIG

Port	Default COS
*	*
ge1/1	0
ge1/2	0
ge1/3	0
ge1/4	0
ge1/5	0

Apply
Cancel

5.3.7 LLDP Config


The link layer discovery protocol (LLDP) is a vendor independent two level protocol, which allows network devices to notify their device identities and performance in the local subnet.


5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

GLOBAL CONFIG
PORT CONFIG
LLDP NEIGHBORS

LLDP ☐ Enable ☒ Disable
Send cycle scope:5-65535, Default:30
Hold Time scope:5-65535, Default:120
Send interval scope:2-5, Default:2
Reinit delay scope:2-5, Default:2
TLV Optional to send ☒ Management address ☒ Port description ☒ System property ☒ System description ☒ System name


5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

GLOBAL CONFIG
PORT CONFIG
LLDP NEIGHBORS

Port	Send	Receive	Management address
*	<input type="text" value="*"/>	<input type="text" value="*"/>	<input type="text" value="*"/>
ge1/1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="text"/>
ge1/2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="text"/>
ge1/3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="text"/>
ge1/4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="text"/>
ge1/5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="text"/>

After successful configuration, view adjacent LLDP information in the upper right LLDP neighborhood

5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

GLOBAL CONFIG PORT CONFIG LLDP NEIGHBORS

LLDP Neighbors shows
 Capability Codes:
 (R)Router,(B)Bridge,(C)DOCSIS Cable Device,(T)Telephone
 (W)WLAN Access Point,(P)Repeater,(S)Station,(O)Other

SerialNum	Device ID	Chassis-ID	management	Local interface	Vlan	Hold Time	Port ID	Capability
<div>Refresh</div>								

5.3.8 DHCP Server Config

A computer DHCP server that manages the DHCP standard in a particular network is responsible for assigning IP addresses when a workstation logs in. And make sure that the IP address assigned to each workstation is different and that the DHCP server greatly simplifies some of the network management tasks that previously needed to be done manually.

5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

DHCP POOL CONFIG LEASES LIST STATIC LEASES CONFIG PORT BIND CONFIG

DHCP Server
DHCPService
☐ Enable

Apply

Pool name

Subnet mask

Lease time

Default gateway

Name server
Domain server
NetBIOS Server

length:1-48

eg:192.168.0.1/24

10 Day 0 Hours 0 Minutes

eg:192.168.0.1

Add

Pool name	Subnet mask	Lease time	Default gateway	Name server	Domain server	NetBIOS Server
<div>Refresh</div>						

5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

DHCP POOL CONFIG LEASES LIST STATIC LEASES CONFIG PORT BIND CONFIG

SerialNum	MAC address	IP address	Expire
Total 0 Entry 20 entrys per page			

1/1Page
Go
Refresh

5 Port Gigabit PoE Powered (PD) Managed Switch
ALL-SG8205PDM
Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

DHCP POOL CONFIG LEASES LIST STATIC LEASES CONFIG PORT BIND CONFIG

Static DHCP Config

DHCP Pool
IP address
MAC address

eg:192.168.0.1

Format: MM:MM:MM:MM:MM:MM

Add


SerialNum	IP address	MAC address	DHCP Pool
Total 0 Entry 20 entrys per page			

1/1Page
Go

© ALLNET GmbH Computersysteme 2018 - Alle Rechte vorbehalten

Irrtum und Änderungen vorbehalten

34



5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

DHCP POOL CONFIG
LEASES LIST
STATIC LEASES CONFIG
PORT BIND CONFIG


Port binding config

DHCP Pool
Port
IP address
Add

eg:192.168.0.1

DHCP Pool	Port	IP address
Refresh		

5.3.9 Time Range Config



5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage
Interface Manage
Business Manage
VLAN Config
MAC Config
Spanning-tree Config
ERPS-Ring Config
L2 mcast-config
QINQ-config
QOS Config
LLDP Config
DHCP Server Config
Time Range Config
Route Manage
Network security
System manage
Save

AddTime

Name	Time
Refresh	

© ALLNET GmbH Computersysteme 2018 - Alle Rechte vorbehalten

Irrtum und Änderungen vorbehalten

35

5.4 Route Manage

5.4.1 L3 interface set up

ALLNET® 5 Port Gigabit PoE Powered (PD) Managed Switch ALL-SG8205PDM Logout

System Manage
Interface Manage
Business Manage
Route Manage
L3 interface
Show route
Static Config
Network security
System manage
Save

AddInte

Interface	Enable	Status	Mode	IP address	Description
vlanif1	<input checked="" type="checkbox"/>	Up	static	192.168.2.1/24	

Apply Refresh

Total 1 Entry 20 entrys per page 1/1Page Go

5.4.2 show route

ALLNET® 5 Port Gigabit PoE Powered (PD) Managed Switch ALL-SG8205PDM Logout

System Manage
Interface Manage
Business Manage
Route Manage
L3 interface
Show route
Static Config
Network security
System manage
Save

Show route
Codes:
K - kernel route, C - connected, S - static, R - RIP, O - OSPF, I - IS-IS, B - BGP, A - Babel, > - selected route, * - FIB route

SerialNum	Destination	Mask	Mark	Gateway	Output port
1	192.168.2.0	24	C>*		vlanif1

Total 1 Entry 20 entrys per page 1/1Page Go

5.4.3 Static Config

ALLNET® 5 Port Gigabit PoE Powered (PD) Managed Switch ALL-SG8205PDM Logout

System Manage
Interface Manage
Business Manage
Route Manage
L3 interface
Show route
Static Config
Network security
System manage
Save

Add static route

Destination prefix / eg:10.1.1.0/24
Gateway eg:20.1.1.3
Distance 1 scope:1-255
Add

SerialNum	Destination prefix	Mask	Gateway	Distance
-----------	--------------------	------	---------	----------

Total 0 Entry 20 entrys per page 1/1Page Go

5.5 Network Security

5.5.1 Access Control

Message processing

ALLNET®

5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Business Manage

Route Manage

Network security

Access Control

Attack protection

ACL Config

Traffic monitor

Alarm-config

System manage

Save

Configure access policy , default is disabled. If specify **allowed**, all host which not matched rule list will be forbidden. Please add rule list first.

☒ Disable

☐ IP listed below, **allowed** access this device.

☐ IP listed below, **forbidden** access this device.

Apply

Cancel

Configure access rule for system

IP address

eg:192.168.0.1/24

Service

ALL

Add

Cancel

SerialNum	IP address	Service
-----------	------------	---------

Total 0 Entry 20 entries per page

1/1Page 1/1Go

5.5.2 Attack protection

ALLNET®

5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Business Manage

Route Manage

Network security

Access Control

Attack protection

ACL Config

Traffic monitor

Alarm-config

System manage

Save

Ignor PING

☐ Enable

☒ Disable

Ignore local device PING

SYN DOS ATTACK

☐ Enable

☒ Disable

TCP SYN ATTACK protection

CPU receive threshold

0

pps

scope:0-100000 (default is 0 , no rate limit)

Apply

Cancel

5.5.3 ACL Config

ALLNET®

5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Business Manage

Route Manage

Network security

Access Control

Attack protection

ACL Config

Traffic monitor

Alarm-config

System manage

Save

ACL GROUP CONFIG

MAC ACL CONFIG

IP ACL CONFIG

Port

☐ ge1/1

☐ ge1/2

☐ ge1/3

☐ ge1/4

☐ ge1/5

Select All

MAC ACL

Empty is delete acl group applied ports

IP ACL

Empty is delete acl group applied ports

Apply

Port	MACACL ListID	IPACL ListID
------	---------------	--------------

Refresh

ACL based on MAC

ALLNET® 5 Port Gigabit PoE Powered (PD) Managed Switch ALL-SG8205PDM Logout

System Manage Interface Manage Business Manage Route Manage Network security Access Control Attack protection ACL Config Traffic monitor Alarm-config System manage Save

ACL GROUP CONFIG MAC ACL CONFIG IP ACL CONFIG

Apply Group Group ID scope:1-99 Add Delete

rule Config

Group ID RuleID ACTION deny ACTION SourceMAC DestMAC SourceIP DestIP Time-RangeName

If no Input , anything is valid
format:A.B.C.D or any
format:A.B.C.D or any
any time is valid if no input

Add Delete

Group ID	RuleID	ACTION	SourceMAC	DestMAC	SourceIP	DestIP	Time-Range
----------	--------	--------	-----------	---------	----------	--------	------------

Refresh

ACL based on IP

ALLNET® 5 Port Gigabit PoE Powered (PD) Managed Switch ALL-SG8205PDM Logout

System Manage Interface Manage Business Manage Route Manage Network security Access Control Attack protection ACL Config Traffic monitor Alarm-config System manage Save

ACL GROUP CONFIG MAC ACL CONFIG IP ACL CONFIG

Apply Group Group ID scope:100-999 Add Delete

rule Config

Group ID RuleID ACTION deny ACTION protocol any ACTION SourceIP SourceMask SourcePort DestIP DestMask DestPort Time-RangeName

scope:100-999
scope:1-127
format:A.B.C.D or any
format:A.B.C.D or any
scope is 0-65535,any port if no input
format:A.B.C.D or any
format:A.B.C.D or any
scope is 0-65535,any port if no input
any time is valid if no input

Add Delete

Group ID	RuleID	ACTION	protocol	SourceIP	SourceMask	SourcePort	DestIP	DestMask	DestPort	TimeRange
----------	--------	--------	----------	----------	------------	------------	--------	----------	----------	-----------

Refresh

5.5.4 Traffic monitor

ALLNET® 5 Port Gigabit PoE Powered (PD) Managed Switch ALL-SG8205PDM Logout

System Manage Interface Manage Business Manage Route Manage Network security Access Control Attack protection ACL Config Traffic monitor Alarm-config System manage Save

Port ☐ ge1/1 ☐ ge1/2 ☐ ge1/3 ☐ ge1/4 ☐ ge1/5 [Select All](#)

Direction ingress

Rate-config unit:Bytes per seconds,Rate thresholdscope:0-1073741824


Add

Port	Direction	Rate
------	-----------	------

Refresh

5.5.5 Alarm-config

This page contains system alarm、link alarm



5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Business Manage

Route Manage

Network security

Access Control

Attack protection

ACL Config

Traffic monitor

Alarm-config

System manage

Save

SYSTEM ALARM

LINK ALARM

Enable ☐

CPU % scope:30-100, Send alarm while overload threshold.

Memory % scope:30-100

Power ☐


Apply

Cancel

CPU usage 0.4%

Memory usage 84% (free:9888 KB, total:60420 KB)

Alarm



5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Business Manage

Route Manage

Network security

Access Control

Attack protection

ACL Config

Traffic monitor

Alarm-config

System manage

Save

SYSTEM ALARM

LINK ALARM

Take effect while global alarm enable

Port	Enable
*	<input type="text" value="*"/>
ge1/1	<input type="checkbox"/>
ge1/2	<input type="checkbox"/>
ge1/3	<input type="checkbox"/>
ge1/4	<input type="checkbox"/>
ge1/5	<input type="checkbox"/>

Apply

Cancel

© ALLNET GmbH Computersysteme 2018 - Alle Rechte vorbehalten

Irrtum und Änderungen vorbehalten

39

5.6 System management

5.6.1 Log Config

ALLNET®

5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Business Manage

Route Manage

Network security

System manage

Log Config

Diagnosis

NTP Config

Reboot

Firmware

Save

TFTP server

log upload

File name

the name of the stored file on the server

Upload

Log-information

2000/01/01 08:00:12 HSM: loading rc.soc
2000/01/01 08:00:17 HSM: Unit 0: Chip=BCM53322_A0 Dev=0xc322 Rev=0x01
2000/01/01 08:00:17 HSM: HW(hsm_hw_init 581) ERR=-18 Invalid port
2000/01/01 08:00:18 HSM: Dxs8 verify 20
2000/01/01 08:00:19 HSM: Board verification OK
2000/01/01 08:00:23 MSTP: Init erps ok
2000/01/01 08:00:26 HSM: HW(hsm_hw_start 544) ERR=-18 Invalid port
2000/01/01 08:00:30 GSM: gel/5 is up
2000/01/01 08:00:30 ZEBRA: vlanif1 changes to UP
2000/01/01 08:00:30 GSM: Init poe ok
2000/01/01 08:00:31 ZEBRA: vlanif1 changes to DOWN
2000/01/01 08:00:31 GSM: gel/5 is down
2000/01/01 08:00:34 GSM: gel/5 is up
2000/01/01 08:00:34 ZEBRA: vlanif1 changes to UP
2000/01/01 08:19:06 WEB: admin login from 192.168.2.99
2000/01/01 08:21:34 WEB: admin@192.168.2.99: user_config&add=2&name=admin
2000/01/01 08:22:17 WEB: admin@192.168.2.99: user_config&add=2&name=admin
2000/01/01 09:00:17 WEB: logout from 192.168.2.99
2000/01/01 09:00:24 WEB: admin login from 192.168.2.99

Clear Refresh

5.6.2 Diagnosis

Maintenance tool

ALLNET®

5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Business Manage

Route Manage

Network security

System manage

Log Config

Diagnosis

NTP Config

Reboot

Firmware

Save

Cable Diag

This may take a few seconds.

Test

PING

eg:192.168.1.1, 2000::1

Test

TRACEROUTE

eg:192.168.1.1, 2000::1

Test

5.6.3 NTP Config

ALLNET®

5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Business Manage

Route Manage

Network security

System manage

Log Config

Diagnosis

NTP Config

Reboot

Firmware

Save

NTP CLIENT CONFIG

NTP SERVER CONFIG

NTP client config

Mode ☒ disabled ☐ unicast ☐ broadcast

Server1 eg:192.168.1.1

Server2

Server3

Apply Cancel

Source	Reference	Stratum	Offset	Delay	Dispersion
Clock status	no				
Clock stratum	16				
Reference clock ID	0.0.0.0				
Root delay	0.000000				
Root dispersion	0.000000				
Reference time	2000-01-01 08:00:24				
Synchronization state	no				

Common Server:

China 202.108.6.95 202.112.29.82

TaiWan 120.119.28.1

America 24.56.178.140 131.107.13.100

Refresh

5.6.4 Reboot

ALLNET®

5 Port Gigabit PoE Powered (PD) Managed Switch

ALL-SG8205PDM

Logout

System Manage

Interface Manage

Business Manage

Route Manage

Network security

System manage

Log Config

Diagnosis

NTP Config

Reboot

Firmware

Save

NTP CLIENT CONFIG

NTP SERVER CONFIG

NTP server config


☐ Enable ntp server

Local as master ☐ stratum 2

Apply Refresh


5.6.5 Firmware

Firmware upgrade



The screenshot shows the ALLNET web interface for a 5 Port Gigabit PoE Powered (PD) Managed Switch (ALL-SG8205PDM). The left sidebar contains a menu with the following items: System Manage, Interface Manage, Business Manage, Route Manage, Network security, System manage, Log Config, Diagnosis, NTP Config, Reboot, Firmware, and Save. The 'Reboot' option is highlighted. The main content area displays a 'Reboot' button with the text 'Click this button, the device will restart!'.

Configuration saves



The screenshot shows the ALLNET web interface for a 5 Port Gigabit PoE Powered (PD) Managed Switch (ALL-SG8205PDM). The left sidebar contains a menu with the following items: System Manage, Interface Manage, Business Manage, Route Manage, Network security, System manage, and Save. The 'Save' option is highlighted. The main content area displays the 'Running-config' page, which shows the current configuration of the switch. The configuration includes the version (2.3.1 build 403), http-server settings, timezone (utc plus 1), and three interfaces (gel/1, gel/2, gel/3) with their respective cos map settings. A 'Save' button is located at the bottom of the configuration area, with the text '(Save the current configuration to the startup file)'.

Startup configuration

ALLNET® 5 Port Gigabit PoE Powered (PD) Managed Switch ALL-SG8205PDM Logout

System Manage
Interface Manage
Business Manage
Route Manage
Network security
System manage
Save

RUNNING-CONFIG THE START CONFIGURATION MANAGEMENT FILE

The Start configuration

```
ip http-server all
ip http-server language en
timezone utc plus 1
!
username admin password gRUaGgRgINK6
!
vlan 1
!
interface gel/1
!
interface vlanif1
ip address 192.168.2.1/24
!
line vty
!
```

Restore (Take effect after reboot) Download

Configuration import

ALLNET® 5 Port Gigabit PoE Powered (PD) Managed Switch ALL-SG8205PDM Logout

System Manage
Interface Manage
Business Manage
Route Manage
Network security
System manage
Save

RUNNING-CONFIG THE START CONFIGURATION MANAGEMENT FILE

File path Keine C

Take effect after reboot

5.7 Save

After configuring the switch, you must choose to save the configuration

5.8 Hardware Specifications

Model	4GE (PoE) +1G (PD) ALL-SG8205PDM
Standard	IEEE 802.3、IEEE 802.3u、IEEE 802.3ab 、IEEE 802.3z、IEEE 802.3x、IEEE 802.1X、 IEEE 802.1q 、IEEE 802.1p、IEEE 802.1d 、IEEE 802.1w、IEEE 802.3ad IEEE802.3af、IEEE802.3at
Network Media(Cable)	10BASE-T: UTP category 3,4,5 cable (≤100m) 100BASE-TX: UTP category 5 cable (≤100m) 1000BASE-T: UTP category 5e,6 cable (≤100m)
MAC Address Table	8K, Auto-learning, Auto-aging
Transfer mode	Store-and-Forward
Frame Forward Rate	10Base-T: 14881pps/Port 100Base-TX: 148810pps/Port 1000Base-T/X: 1488095pps/Port
Switching Capacity	10Gbps
Dimensions (L*W*H)	168×93×32mm
Fan	Fanless
Power supply	DC 55V/1.1A (Max)
PoE Port	Port1~4
PoE Power on RJ45	Mode A 1/2(+),3/6(-)
PoE Power Output	Voltage: 55V DC Power: 32W(Max)
PoE Power Budget	55W
Temperature	Operating Temperature: 0°C ~ 40 °C (32 °F ~104°F) Storage Temperature: -40 °C ~ 70 °C (-40 °F ~158°F)
Humidity	Operating Humidity: 10% ~ 90% non-condensing Storage Humidity: 5% ~ 90% non-condensing

ALLNET GmbH Computersysteme declares that the device **ALL-SG8205PDM** is in compliance with the essential requirements and other relevant provisions of Directive 2014/30/EU. The Declaration of conformity can be found under this link: <http://ce.allnet.de/>

ALLNET GmbH Computersysteme
Maistrasse 2
82110 Germering

Tel.: +49 (0)89 894 222 - 22
Fax: +49 (0)89 894 222 - 33
Email: info@allnet.de



Safety Instructions

For your safety, be sure to read and follow all warning notices and instructions.

- Do not open the device. Opening or removing the device cover can expose you to dangerous high voltage points or other risks. Only qualified service personnel can service the device. Please contact your vendor for further information.
- Do not use your device during a thunderstorm. There may be a risk of electric shock brought about by lightning.
- Do not expose your device to dust or corrosive liquids.
- Do not use this product near water sources.
- Make sure to connect the cables to the correct ports.
- Do not obstruct the ventilation slots on the device.

GPL Declaration for ALLNET products

DISCLAIMER_OF_WARRANTY

This Program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; version 2 of the License.

This Program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this Program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA.

The full text of the GNU General Public License version 2 is included with the software distribution in the file LICENSE.GPLv2

NO WARRANTY

BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Written Offer for Source Code

For binaries that you receive from ALLNET GmbH Computersysteme on physical media or within the download of the offered firmware that are licensed under any version of the GNU General Public License (GPL) or the GNU LGPL, you can receive a complete machine-readable copy of the source code by sending a written request to:

ALLNET GmbH Computersysteme
Maistrasse 2
82110 Germering

Your request should include: (i) the name of the covered binary, (ii) the version number of the ALLNET product containing the covered binary, (iii) your name, (iv) your company name (if applicable) and (v) your return mailing and email address (if available). We may charge you a nominal fee to cover the cost of the media and distribution. Your request must be sent within three (3) years of the date you received the GPL or LGPL covered code. For your convenience, some or all of the source code may also be found at:

<http://www.allnet.de/gpl.html>

LICENSE.GPLv2

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc. 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA

© ALLNET GmbH Computersysteme 2018 - Alle Rechte vorbehalten

Irrtum und Änderungen vorbehalten

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software—to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it. For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:
- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
 - b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
 - c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.
5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.
6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.
7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.
9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

© ALLNET GmbH Computersysteme 2018 - Alle Rechte vorbehalten

Irrtum und Änderungen vorbehalten

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.
12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the program's name and a brief idea of what it does.> Copyright (C) <year> <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA

Also add information on how to contact you by electronic and paper mail. If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w'.

This is free software, and you are welcome to redistribute it under certain conditions; type `show c' for details.

The hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w' and `show c'; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program

`Gnomovision' (which makes passes at compilers) written by James Hacker.

© ALLNET GmbH Computersysteme 2018 - Alle Rechte vorbehalten

Irrtum und Änderungen vorbehalten

<signature of Ty Coon>, 1 April 1989

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.

LICENSE.LGPLv2.1

GNU LESSER GENERAL PUBLIC LICENSE

Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc. 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, version 2, hence the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages--typically libraries--of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish); that you receive source code or can get it if you want it; that you can change the software and use pieces of it in new free programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others. Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary

General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

GNU LESSER GENERAL PUBLIC LICENSE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".
A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.
The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)
"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.
Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.
1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:
 - a) The modified work must itself be a software library.
 - b) You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.
 - c) You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.
 - d) If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful.
(For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

- a) Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)
- b) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.
- c) Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.
- d) If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.
- e) Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:
 - a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.
 - b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.
8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.
9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.
10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.
11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.
 If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.
 It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.
 This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.
12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.
13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.
 Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version

or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.
16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Libraries

If you develop a new library, and you want it to be of the greatest possible use to the public, we recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

To apply these terms, attach the following notices to the library. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the library's name and a brief idea of what it does.> Copyright (C) <year> <name of author>

This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details.

You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Also add information on how to contact you by electronic and paper mail.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the library, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the library 'Frob' (a library for tweaking knobs) written by James Random Hacker.

<signature of Ty Coon>, 1 April 1990 Ty Coon, President of Vice

That's all there is to it!