

VDSL2 Modem

ALL126AM2 (CO) / ALL126AS2 (CPE) USER'S MANUAL

Best viewed at full screen.

VDSL2 Point to Point Solution

VDSL2 (Very-High-Bit-Rate Digital Subscriber Line 2, ITU-T G.993.2 Standard) is an access technology that exploits the existing infrastructure of copper wires that were originally deployed for <u>POTS</u> services. It can be deployed from central offices, from fibre-fed cabinets located near the customer premises, or within buildings.

ITU-T G.993.2 VDSL2 is the newest and most advanced standard of <u>DSL</u> broadband wireline communications. Designed to support the wide deployment of Triple Play services such as voice, video, data, high definition television (HDTV) and interactive gaming, VDSL2 enables operators and carriers to gradually, flexibly, and cost efficiently upgrade existing xDSL-infrastructure.

ITU-T G.993.2 (VDSL2) is an enhancement to G.993.1 <u>VDSL</u> that permits the transmission of asymmetric and symmetric (Full-Duplex) aggregate data rates up to 200 Mbit/s on twisted pairs using a bandwidth up to 30 MHz.

VDSL2 deteriorates quickly from a theoretical maximum of 200 Mbit/s (Full-Duplex) at 'source' to 100 Mbit/s at 0.3 km (symmetric).

CONTENT

1.	Unpacking Information	3
	Checkl List	3
2.	Installation	4
	Hardware Installation	4
	2.1 Pre-installation Requirements	4
	General Rules	5
	Connecting the ALL126AM2/AS2	5
3.	Hardware Description	6
4.	Setup the ALL126AM2/AS2 by Web Browser	10
	4.1 Login	10
	4.2 Run the Setup Wizard	11
	4.3 Select LAN	13
5.	Building a VDSL2 System	16
	5.1 Connect the CO and the CPE to the Line	17
	5.2 Connect the CO and the CPE to the LAN Devices	17
	5.3 Run Demos and Tests	17
6 .	Operating the VDSL 2	19
	6.1 Configuration Settings	19
	6.2 Status Displays	25
7.	Configuration Interface of the Router	29
	7.1 Logging on the ALL126AM2/AS2	29
	7.2 Configuration Menu for Administrators	30
Ар	pendix A: Product Features & Specification	64
Ар	pendix B: Troubleshooting	<mark>68</mark>
Ар	pendix C: Compliance and Safety Information	69
Ap	pendix D: CE Certification	70
Ар	pendix E: GPL Declaration	72

1.Unpacking Information

Check List

Carefully unpack the package and check its contents against the checklist.

Package Contents

- VDSL2 Modem (ALL126AM2 (CO) / ALL126AS2 (CPE))
- Two plastic feet
- User's Manual
- AC to DC 12V Power Adapter
- RJ-45 cable
- RJ-11 cable

Please inform your dealer immediately for any missing, or damaged parts. If possible, retain the carton, including the original packing materials. Use them to repack the unit in case there is a need to return for repair.

2. Installation

Hardware Installation

This chapter describes how to install the ALL126AM2/AS2 and establishes network connections. You may install the ALL126AM2/AS2 on any level surface (e.g, a table or shelf). However, please take note of the following minimum site requirements before you begin.

2.1 Pre-installation Requirements

Before you start actual hardware installation, make sure you can provide the right operating environment, including power requirements, sufficient physical space, and proximity to other network devices that are to be connected. Verify the following installation requirement:

- Power requirements: DC12V/1A or above.
- The ALL126AM2/AS2 should be located in a cool dry place, with at least 10cm/4in of space at the front and back for ventilation.
- Place the ALL126AM2/AS2 out of direct sunlight, and away from heat sources or areas with a high amount of electromagnetic interference.
- Check if network cables and connectors needed for installation are available

General Rules

Before making any connections to the ALL126AM2/AS2, note the following rules:

•Ethernet Port (RJ-45)

All network connections to the Modem Ethernet port must be made using Category 5 UTP for 100Mbps;

Category 3,4 UTP for 10Mbps.

No more than 100 meters of cabling may be use between the MUX or HUB and an end node.

•Phone Port (RJ-11)

All Phone set connections to the RJ-11 Port made using 24~26 Gauge phone wiring.

Connecting the ALL126AM2/AS2

The ALL126AM2/AS2 can be controlled by a PC, henceforth, called the "Control PC". For this purpose, you need

a PC with an Ethernet network interface and a DB-9 RS232 serial interface. Two programs are required: A Web

browser is mandatory and a terminal program should be available optionally.

The board has several connectors.

- 4 Ethernet RJ45 jacks (connect LAN devices to route); the Auto MDIX feature of the ports switches automatically between MDI and MDI-X (MDI = Media Dependant Interface), therefore straight Ethernet cables can be used.
- 2 x RJ11 jack (LINE Port is for connects VDSL client side to Line Interface, Phone port is for connects phone set or FAX machine)
- •1 x Console port (monitoring, access to operating system via shell for firmware downloads, starting drivers and web etc.,)
- •1 Power Supply (as described above)



Figure 2.1 VDSL2 Point to Point application

(C) 2007 ALLNET GmbH - www.allnet.de

3. Hardware Description

This section describes the important parts of the ALL126AM2/AS2. It features the front indicators and rear connectors.

Front Indicators

The following figure shows the front panel.



Figure Chapter 3.1 ALL126AM2

Six LED indicators.

At a quick glance of the front panel, it will be easy to tell if the modem has power, signal from its Ethernet RJ-45 port or there is phone line signal RJ-11port

(C) 2007 ALLNET GmbH - www.allnet.de

Front Indicators

LED Description and Operation The Modem has three LED indicators.

LEDs	Status	Descriptions
PWR (Ready LED)	Steady Green	It will light up (ON) to show that the product is power good, and system reset OK.
E1~E4 (Ethernet LED) Steady Green Flashing (LINK/ACT)		Each RJ-45 station port on the Ethernet is assigned an LED light for monitoring port "Good Linkage". LED is normally OFF after the power on operation, but will light up steadily to show good linkage and flashing to show data transmission.
Link (VDSL LED)	.ED) Steady Green Green RJ11 station port on the VDSL is as LED light for monitoring port "Good LED is normally OFF after the operation, but will light up steadily to s linkage.	

Rear Panel

The following figure shows the rear connectors

Figure Chapter 3.3 Rear Connectors



ALL126AM2/AS2 Rear Connectors

<u>Connectors</u>	Description	Type
Line For connecting to the VDSL Modem Using a RJ-11 cable		RJ-11
<u>Phone</u>	Phone For connecting to the telephone or Fax ISDN modem	
E1~E4 For connecting to a Ethernet equipped device		RJ-45
Console port For connecting to PC with RS-232 serial port over a D-SUB Cable		RS-232

Power On

- 1. Check the adapter is properly connected.
- 2. Verify the power LED is steadily on.

4. Setup the ALL126AM2/AS2 by Web Browser

The ALL126AM2/AS2 provides a built-in web browser. You can use Web browser to configure the ALL126AM2/AS2. First please input the IP address 192.168.16.249 (ALL126AM2 (CO) and 192.168.16.250 (ALL126AS2 (CPE)) in the Web page.

<u>4.1 Login.</u>

The password is "admin".

LOGIN PASSWORD		
Password:		
	LOGIN	CANCEL

Figure 4.1 Login

4.2 Setup Wizard

There is a simple Setup Wizard for end users and an Advanced Setup Menu. You have to run the Setup Wizard on both VDSL2 Modems to configure the VDSL2 Connection

4.2.1 Host & Domain Name

Configure Host Name and Domain Name on the ALL126AM2 and the ALL126AS2

	<u>SYS</u>	TEM WAN LAN NAT FIRE	WALL ROUTE UPNP VDSL2 SUPPORT Setup Wizard
→ Administrator Setting			
→ Firmware Upgrade	V 1. Host Settings		
→ Device Mode	🔿 2. WAN Type		
→ System Status	O 3. WAN Settings	Host Name	VDSL2_CO_master
→ System Log	O 4. DNS	riostrianio	
→ Reboot		Domain Name	alinet.de
→ Reset System			
		Enter the unique host name for	the , and the domain name of your organization.
	Figure 4	.2.1 Mastermodem config	guration
	SYS	<u>TEM WAN LAN NAT FIRE</u>	WALL ROUTE UPNP VDSL2 SUPPORT Setup Wizard
→ Administrator Setting			
→ Firmware Upgrade	V 1. Host Settings		
→ Device Mode	O 2. WAN Type		
→ System Status	O 3. WAN Settings	Host Name	VDSL2 CPE client
→ System Log	O 4. DNS		
→ Reboot		Domain Name	allnet.de
→ Reset System			
		Enter the unique host name for	the , and the domain name of your organization.

Figure 4.2.2 Clientmodem configuration

(C) 2007 ALLNET GmbH - www.allnet.de

4.2.2 WAN Type

In this Menu you can configure the WAN Type on the ALL126AM2/AS2. The following Connectionstypes can be selected:

- Cable Modem
- Fixed-IP xDSL
- Dial-UP xDSL (PPPOE)

SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP YDSL2 SUPPORT Setup Wizard			
→ Administrator Setting			
→ Firmware Upgrade	🎯 1. Host Settings		
→ Device Mode	🎯 2. WAN Type	Specify the WAN connection type required by your Internet Service Provider. Specify a Cable modern, Fixed-IP xDSL, or PPPoE xDSL.	
→ System Status	🔘 3. WAN Settings		
→ System Log	🔾 4. DNS	🖸 🚰 🔂 Cable Modern	
→ Reboot		A Cable modem requires minimal configuration. When you have set up an account with your Cable provider, the Cable modem will automatically configure itself, so	
→ Reset System		you probably do not need to enter anything more. However, if there is a Domain Name System (DNS) server that you would rather use, you need to speci address.	
		C Fixed-IP xDSL Some xDSL Internet Service Providers may assign a fixed IP address for your. If you have been provided with this information, choose thisoption and enter the	
		assigned IP address, subnet mask, gateway IP and DNSIP addresses for your .	
		If you connect to the Internet using an xDSL Modem and your ISP has provided you with a password, and Service Name, then your ISP uses PPPoE. You must choose this option and enter the required information.	

Figure 4.2.3 WAN Type

4.3 Select LAN

The menus below will not be used very often. But when connecting the ALL126AM2/AS2 to a new control PC, you may want to go through the following steps in order to make the IP address previously set by ifconfig in the terminal console permanent. Or on some later occasion you may want to change it again without using the console. Then the menu below will help you too. In order to set the IP address, click on "LAN Settings".



Figure 4.3 LAN menu

4.3.1 Select LAN Settings and set the IP Address

The form below is used to change the IP address of the LAN port "adm0" in the ALL126AM2/AS2.

- The proposed IP address either is the default address of adm0 or it is the address changed by an ifconfig command via the shell running in the terminal.
- The Subnet Mask display can be ignored.
- In case the DHCP checkbox is checked, some additional data and options will be on display (see Chapter 7.2.4.1 on Page 50). The DHCP server is not required to work with VDSL2 in a lab environment. It is recommended to uncheck the box if it is not unchecked already.

	SYSTEM W	AN LAN NAT FIREWALL ROUTE UPNP VDSL2 SUPPORT
→ LAN Settings		
→ DHCP Client List	LAN Settings	
→ LAN Switch Port Setting	EAN Settings	
→ LAN Port Status	You can enable DHCP to dynamically allocate IP addresses to your client PCs.	
	IP Address	192 168 16 249
	Subnet Mask	255 255 0
	The Gateway acts as DHCP Server	Enable

Figure 4.3.1 LAN Settings

Now the IP address either may be changed or left as it is. If it has been changed in the form or after it has been changed using the ifconfig command via the shell running in the terminal, it needs to be stored permanently Hit the "APPLY" button in order to make the displayed IP address new default address.

4.3.2 Restart the Settings Dialog

After the "APPLY" button has been hit, the displayed IP address "adm0" port will be stored in a non volatile memory on the ALL126AM2/AS2. Also, the Ethernet link between the control PC and the ALL126AM2/AS2 will be re-initialized – even if the IP address has not been changed. Refresh the display of the HTTP browser running on the control PC and login again.

LOGIN	PASSWORD
Password:	
	LOGIN CANCEL

Figure 4.4.2 Login after Storing the IP Address as Default Value

The ALL126AM2/AS2 now is prepared to be controlled by the control PC.

5. Building a VDSL2 System

First a quick overview over a complete setup:



Figure 5 VDSL2 Application

5.1 Connect the ALL126AM2 (CO) and the ALL126AS2 (CPE) to the Line

The objective for VDSL2 is passing data over a twisted pair cable at high speed. In the setup, either such a cable connects the ALL126AM2 (CO) and the ALL126AS2 (CPE), or a line simulator or any other hardware representation of a cable network, with or without noise injection and crosstalk simulations.

5.2 Connect the ALL126AM2 (CO) and the ALL126AS2 (CPE) to LAN Devices

In the setup, usually a Ethernet tester serves as representation of the LAN side as well as representation of the WAN side.

5.3 Run Demos and Tests

The Ethernet tester may send data downstream as well as upstream. It also receives the data in order to check the integrity of the data transmission.

Different data rates can be tested under different line conditions.

6. Operating the VDSL2 System

After the VDSL2 system has been set up, you may want to configure the settings which are related to VDSL2. Configuration of operation modes, test modes (loop back) and the display of status information is supported by an graphical user interface.

6.1 Configuration Settings

Configure and start the ALL126AM2 (CO) and the ALL126AS2 (CPE)

- •Configuration: As a minimum configuration, usually selecting the bandplan is required. See Chapter 6.1.3, Profile Configuration.
- •Next, both sides should be activated from the web interface. See Chapter 6.1.6, Line Activation
- •The connection status of the link can be monitored. See Chapter 6.2.1, Line Status

6.1.1 Channel Configuration

This function is for setting VDSL channel. Click on VDSL 2 and then on Channel config

		YSTEM I WAN I LAN I NA	T FIREWALL ROUTE UPNP	VDSL2 SUPPORT
Channel Config Une Config Profile Config Profile Config Rende Config	Channel Config			
LoopBack	Chamilan haverber:	Channell 💌		
Activate/Deactivate	Christelin	Upstream 💌		
Channel Status	Min Data Rate	64	1664	
version Into INR Graph	Main Dista Rade	102400	(Adapts	
lita Graph	Maxintoniana Dolay	15	in the second	
				000

Figure 6.1.1 Channel Configuration Menu

on octaings			
Description			
To which bearer channel number shall the settings apply?			
•Channel 0			
To which direction shall the settings apply?			
•Upstream			
•Downstream			
Minimum Payload Data Rate			
Maximum Payload Data Rate			
Maximum Interleaver Delay			

Channel Configuration Settings

(C) 2007 ALLNET GmbH - www.allnet.de

Note: The Reboot is needed for saving the new settings. 6.1.2 Line Configuration

		<u>SYSTEM WAN LAN NAT FIREWALL</u>	ROUTE UPNP VDSL2 SUPF	ORT
→ Channel Config				
→ Line Config	Line Config			
→ Profile Config	Line coming			
→ Bands Config				
→ LoopBack	Direction	Upstream 💌		
→ Activate/Deactivate	Toroot SNIDM	000000	σι	
→ Line Status	Talget Sinkin	8.000000	db/	
→ Channel Status				
→ Version Info				
→ SNR Graph				
→ Bits Graph				
				HELP APPLY CANCED

Figure 6.1.2 Line Configuration Menu for SNR Margin Selection

Line Configuration

Setting	Description
Direction	Select the target direction.
Target SNRM	Set the required SNR Margin *10 (60=6dB)

(C) 2007 ALLNET GmbH - www.allnet.de

6.1.3 Profile Configuration

For this function, ALL126AM2/AS2 provides world wide telecom standard band plan, such as meet European telecom standard band plan 998(17a), USA telecom standard band plan 997(8a, 8b) and Janpan Telecom standard band plan (30a) etc.

Annex A specifies bandplans for the North American region and enables ALL126AM2/AS2 to be deployed with traditional POTS telephony or in an all-digital mode. Annex B specifies bandplans for Europe and enables ALL126AM2/AS2 deployment with underlying POTS and ISDN services. Annex C allows ALL126AM2/AS2 to coexist with TCM-ISDN services, found primarily in Japan.

ALL126AM2/AS2 has numerous configuration profiles and bandplans to meet regional service provider requirements. The frequency bandwidth has increased to 30 MHz, with configuration options at 8.5 MHz, 12 MHz, 17.7 MHz and 30 MHz.

Note : Please deactivate then activate once when any band profile is being changed. This version does not support ADSL band profile, but will support that in the near future.

		SYSTEM I WAN I LAN I NAT I FIREWALL I ROUTE I UPNP I VIDSLZ I SUPPORT
 ← Channel Contig ← Line Contig ← Protile Contig 	Profile Config	
+ Banda Config + LoopBack	Profile	Vdst2 Profile30s -
Activate/Deactivate Line Status	BasdPlan	Bandplan ITU Annex C_BK 🔄
Channel Status Version Info SNR Graph Bits Graph	(File)	Additional Filter Qf

Figure 6.1.3 Profile Configuration

6.1.4 Band Configuration

This function is for setting tones for each band.



Figure 6.1.4 Band Configuration

6.1.5 Loop Back

The loop back testing function for checking phone wire link problem: 1. System Loop 2. Line Side Loop

	SYST	EM <u>WAN LAN NAT FIREWALL ROUTE UPNP</u> <u>VDSL2</u> <u>SUPPORT</u>
→ Channel Config		
→ Line Config	Loop Back	
→ Profile Config	Loop Back	
→ Bands Config		
→ LoopBack	Channel Number	Channel0 💌
→ Activate/Deactivate	Loop	System - System Loon 💌
→ Line Status	Loop	
→ Channel Status	State	Deactivate 💌
→ Version Info		
→ SNR Graph		
→ Bits Graph		
		HELP) APPLY CANCEL

Figure 6.1.5 Loop Back Activation/Deactivation Menu

Loop Back

Setting	Description
Channel	To which bearer channel number shall the settings apply?
Number	•Channel 0

6.1.6 Line Activation

This function is for enable/disable VDSL2 port.

	<u>SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP YDSL2 SUPPORT</u>
→ Channel Config	
→ Line Config	Activate Deactivate
→ Profile Config	
→ Bands Config	Activation or Departmention the line
→ LoopBack	Activating of Deactivating the line
→ Activate/Deactivate	
→ Line Status	Line Activate 💌
→ Channel Status	
→ Version Info	
→ SNR Graph	
→ Bits Graph	
	HELP APPLY CANCED

Figure 6.1.6 Activation and Deactivation of the Line

Line Activation/Deactivation

Setting	Description
Line	Activate or deactivate the line. (Select the activity and the press
	the APPLY button.)

6.2 Status Displays

6.2.1 Line Status

This function provides SNR value for checking phone wiring quality.

	<u>S1</u>	<u> (STEM WAN LAN NAT FIREWALL ROUT</u>	E UPNP VDSL2 SUPPORT
→ Channel Config			
→ Line Config	Line Status		
→ Profile Config	Ente orditus		
→ Bands Config	Status of the Line		
→ LoopBack	Status of the Eme.		
→ Activate/Deactivate		A ASS AND STORE	
→ Line Status		Upstream	Downstream
→ Channel Status	State	showtime to sync	showtime to sync
→ Version Info	Donald Actual OND	7 600000 4P	10 200000 HP
→ SNR Graph	Dahu TActual SINK	7.600000 dB	10.500000 UB
→ Bits Graph	Band2 Actual SNR	6.700000 dB	8.900000 dB
	Band3 Actual SNR	10.900000 dB	9.500000 dB
	Band4 Actual SNR	-3276.800049 dB	-3276.800049 dB
	Band5 Actual SNR	-3276.800049 dB	-3276.800049 dB

Figure 6.2.1 Line Status Display: Actual SNR

The following status messages may occur: not_initialized, exception, idle request, idle, silent request, silent, handshake, full init, discovery, training, analysis, exchange, showtime no sync, showtime tc sync, fast retrain, lowpower I2, loopdiagnostic, loopdiagnostic complete, resync, test, lowpower I3, unknown

6.2.2 Channel Status

This function show VDSL2 port status.

<u>SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP VDSL2 SUPPORT</u>			
→ Channel Config			
→ Line Config	Channel Status		
→ Profile Config	onamici otatus		
→ Bands Config	Otatus of the hoerer		
→ LoopBack	Status of the bearer.		
→ Activate/Deactivate			
→ Line Status	Channel Number	Channel0 🗾	
→ Channel Status		Upstream	Downstream
→ Version Info			
→ SNR Graph	Actual Data Rate	102392 kbps	102392 kbps
→ Bits Graph	Actual Interleave Delay	0.000000 ms	0.000000 ms
	Total CRC Count	0	0
	Total FEC Count	0	0
	Actual INP	0.000000 Symbols	0.000000 Symbols

Figure 6.2.2 Channel Status Display: Data Rate, Delay, Error Counters and Impulse Noise Protection

6.2.3 Version Info

This function show hardware and firmware version.

	<u>SY8</u>	STEM WAN LAN NAT FIREWALL ROUTE UPNP YDSL2 SUPPORT	
→ Channel Config			
→ Line Config	Version Info		
→ Profile Config			
→ Bands Config	Varcian Numbers	Version Numbers.	
→ LoopBack	version numbers.		
→ Activate/Deactivate			
→ Line Status	Web Interface Version	B.9.4a	
→ Channel Status	DSL APILibrary Version	1461	
→ Version Info			
→ SNR Graph	Chip Set FW Version	9531502	
→ Bits Graph	Chip Set HW Version	VINAX-DFE_V1.3_mono_reticle	
	DSL Driver Version	0.1.0.2	

Figure 6.2.3 Display of Version Data

6.2.4 SNR Graphs

When ALL126AM2 (CO) link with ALL126AS2 (CPE), this graph will show the SNR value for each band.



Figure 6.2.4 Display of SNR per Carrier

7. Configuration Interface of the Router

This section explains how to configure the router section of the ALL126AM2/AS2 using its web-based configuration.

The parts of the circuitry as well as the router configuration menu has been ported from that of the reference kit to the ALL126AM2/AS2 reference board. As for the menu, There are only a few differences:

- The "adm1" port now is the port to the VDSL2 side. The port on the LAN is "adm0". It supports four Ethernet connections.
- The IP addresses are used in this chapter are different from the examples in the previous chapters.
- The password used in this chapter is different from the examples in the previous chapters.
- The ALL126AM2/AS2 of course has no menu option for VDSL settings. The ALL126AM2/AS2 Series has a VDSL menu which is described in Chapter 6. Also the entry menu (Chapter 4.2) has different "looks" tailored to the ALL126AM2/AS2.
- 7.1 Logging on to the ALL126AM2/AS2

To log on to the ALL126AM2/AS2 Web Application, you must have a valid password. The Administrator creates the log on user with its password. When you log on to the ALL126AM2/AS2 Web Application, the USER LOGIN window is displayed as shown in Figure 7.1.

LOGIN PASSWORD		
Password:		
	LOGIN	CANCEL

Figure 7.1 ALL126AM2/AS2 Web Application

In the USER LOGIN window:

- 1. Enter the password in the Password text box. For an Admin user, the default password is "admin".
- 2. Click LOGIN to begin the configuration or click CANCEL in the USER LOGIN window to cancel this log on operation.

7.2 Configuration Menu for Administrators

This chapter is only for Administrators.

The Homepage is the first screen displayed when a user logs on to the ALL126AM2/AS2 Web Application.

The ALL126AM2/AS2 Web Application is categorized into two modules:

Advanced Setup — Advanced setup features allow the user to configure all the functions that are supported by the ALL126AM2/AS2 like Firewall, routing, UPnP.

7.2.1 Home Setup

The following configuration options are displayed in the top navigation bar, as shown in Figure 7.2.1:

•System

•WAN

- •LAN
- •NAT

Firewall

Route

•UPnP

•vdsl2

	<u>SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP VDSL2 SUPPORT</u>
→ Administrator Setting	
→ Firmware Upgrade	
→ Device Mode	
→ System Status	
→ System Log	
→ Reboot	
→ Reset System	

Figure 7.2.1 Advanced Setup

7.2.2 System

The System link can be viewed in the left navigation bar. The following are the options available under System, as shown in Figure 7.2.2 :

- Administrator Settings
- Firmware Upgrade
- Device Mode
- System Status
- System Log
- Reboot
- Reset System

	<u>SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP VDSL2 SUPPORT</u>
→ Administrator Setting	
→ Firmware Upgrade	Custom Patting
→ Device Mode	System Setting
→ System Status	The VDSL2 CO Modem supports advanced functions like hacker attackdetection, client filtering, virtual servers, special application access, and a virtual DMZ host.
→ System Log	
→ Reboot	
→ Reset System	

Figure 7.2.2 System in the Left Navigator Bar

7.2.2.1 Administrator Settings

To add a user or change user's password, click on the Administrator Settings link in the left navigation bar. A screen is displayed as shown in Figure 7.2.2.1.

	<u>SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP VDSL2 SUPPORT</u>		
→ Administrator Setting			
→ Firmware Upgrade	Administrator Setting		
→ Device Mode	Autoristicator Settings		
→ System Status	Set a password to restrict management access to the . If you want to manage the from a remote location (outside of the local network), you must also specify the IP address of the remote PC.		
→ System Log			
→ Reboot			
→ Reset System	Current Password		
	Password		
	Re-type password	(3-12 Characters)	
	Auto-Logout Time	Min (Auto-Logout Time, at least >= 1 Min)	

Figure 7.2.2.1 Administrator Settings Configuration

While adding a user, each user must be assigned a separate port. Hence the number of users that can be added to the system depends on the number of ports available on the ALL126AM2/AS2. The screen contains the following details:

Fields in User Setting

Field	Description
Current	This is the password associated with the administrator. This is enabled only for the
Password	user Administrator login.
Password	This is the password of the login administrator.
Re-type	This is the password verification.
Password	
Auto-Logout	The auto-logout time, at least one minute.
Time	

• Click CANCEL to exit from this page without saving the changes.

• Click APPLY to save the information that has been entered.

7.2.2.2 Firmware Upgrade

To update the system firmware, click on the Firmware Upgrade link in the left navigation bar. A screen is displayed as shown in 7.2.2.2

	<u>SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP VDSL2 SUPPORT</u>
→ Administrator Setting	
→ Firmware Upgrade	Firmware Update
→ Device Mode	
→ System Status	
→ System Log	
→ Reboot	Enter the path and name of the upgrade file then click the APPLY button below. You will be prompted to confirm the upgrade.
→ Reset System	Runtime Version: 2.4.20_mvl31-ADM5120 #1047 Wed Jun 27 16:03:33 CST 2007
	Durchsuchen

Figure 7.2.3.5 Firmware Update

The screen contains the following detail:

- Click Browse to select a specified file name to change the File Name.
- Click APPLY to start the firmware update.
7.2.2.3 Device Mode

The ADM5120 network processor used in the reference system is able to act as either a switch or a router. Clicking on Device Mode on the left navigation bar allows the user to change the mode of operation, as shown in the following figure.

	SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP VDSL2 SUPPORT
→ Administrator Setting	
→ Firmware Upgrade	Device Mode
→ Device Mode	
→ System Status	The Device mode allows the user to specify the mode setting for the Router. Users can choose Router or Switch mode.
→ System Log	
→ Reboot	
→ Reset System	 Router Mode Switch Mode

Figure 7.2.2.3 Device Mode

7.2.2.4 System Status

To view system status, click on the System Status link in the left navigation bar. A screen is displayed as shown in Figure 7.2.2.4

		SYSTEM I WAN I LAN I NAT I EIREWALL I ROUTE I UPNP I YDSL2 I SUPPORT		
 Administrator Setting 				
 Firmware Upgrade 	Status			
Device Mode Evolution				
• System Log • Rebost	You can use the Status screen to see the connection status for the Routers WANILAN interfaces, firmware and hardware version numbers, and the number of connected clients to your network			
 Reset System 	INTERNET			
	WANIP	00.00		
	Subnet Mask	00.00		
	Gateway	0000		
	DNS	08.00		
	Secondary CNS	00.00		
	Connection Type	FIRED		
	GATEWAY			
	P Address	192 168 16 249		
	Subnet Mask	255.255.255.0		
	DHCP Server	Diseble		
	Firmost	Directes		
	INFORMATION			
	Connected Clients	0		
	Runtime Code Version	1 2.4.20_mM31-ADM5120.#1047 Wed Jun 27 16:03.33 CST 2007		
	LANMAC Address	00.05-9E-00.54 7E		
	WANMAC Address	00.65年60.54 在		
	Hardware Version	10060		

Figure 7.2.3.6 Status Window

This screen displays the status of certain important system parameters. It also offers control over the current DHCP lease for the IP Address.

Click Release to release IP Address for the WAN interface.

Click Renew to renew the IP Address for the WAN interface.

7.2.2.5 System Log

To view the system logs, click on the System log link in the left navigation bar. A screen is displayed as shown in Figure 7.2.2.5.

	SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP YDSL2 SUPP	ORT
→ Administrator Setting		
→ Firmware Upgrade	Coourity Log	
→ Device Mode	Security Log	
→ System Status		
→ System Log	View any attempts that have been made to gain access to your network.	
→ Reboot		
→ Reset System	Log File	
	Jan 1 22:00:02 (none) syslog.info MARK Jan 1 22:20:02 (none) syslog.info MARK Jan 1 22:40:02 (none) syslog.info MARK Jan 1 23:00:02 (none) syslog.info MARK Jan 1 23:20:02 (none) syslog.info MARK Jan 1 23:20:02 (none) syslog.info MARK Jan 1 23:20:02 (none) syslog.info MARK Jan 2 00:00:02 (none) syslog.info MARK Jan 2 00:00:02 (none) syslog.info MARK Jan 2 01:00:02 (none) syslog.info MARK Jan 2 01:00:02 (none) syslog.info MARK -	(FEP)

Figure 7.2.2.5 Security Logs

The screen contains the following details:

Fields in Security Logs

· · · · ·	
Field	Description
	Description
I og File	This lists all the system events.

- Click Download to download the log file to the computer.
- Click Clear to clear this page.
- Click Refresh to retrieve system event and update the log file.

7.2.2.6 Reboot

To reboot the unit, click on the Reboot link in the left navigation bar. A screen is displayed as shown in Figure 7.2.2.6.



Figure 7.2.2.6 Reboot ALL126AM2/AS2 Modem

Click Reboot to reboot the unit.

7.2.2.7 Reset system

To reset the system, click on the Reset link in the left navigation bar. A screen is displayed as shown in Figure 7.2.2.7.

	<u>SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP VDSL2 SUPPORT</u>			
→ Administrator Setting				
→ Firmware Upgrade	Pacat System			
→ Device Mode	Reset System			
→ System Status	Pacat System to default configuration			
→ System Log	Reset System to derault conliguration.			
→ Reboot				
→ Reset System	Reset			

Figure 7.2.2.7 Reset ALL126AM2/AS2 Modem

Click Reset to restart the system.

7.2.3 WAN

The WAN settings can be viewed in the left navigation bar. The following are the options available under WAN, as shown Figure 7.2.3:

- Dynamic IP
- Static IP
- PPPoE
- DNS

	<u>SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP VDSL2 SUPPORT</u>
→ Dynamic IP	
→ IP Settings	
→ PPPoE	
→ DNS	

Figure 7.2.3 WAN Setting in Left Navigator Bar

7.2.3.1 Dynamic IP

To configure the WAN interface to dynamically obtain an IP Address, click on the Dynamic IP link in the left navigation bar. A screen is displayed as shown in Figure 7.2.3.1.

<u>SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP YDSL2 SUPPORT</u>		
→ Dynamic IP		
→ IP Settings	Dynamic IP	
→ PPPoE		
→ DNS	The Host Name is optional, but may be required by some Service Provider's. The default MAC address is set to the WAN's physical interface on the . If required by your Service Provider, use the "Clone MAC Address" button to copy the MAC address of the Network Interface Card installed in your PC and replace the WAN MAC address with this MAC address. The BigPond login is optional, commonly used in Australia. If your ISP need you to do the BigPond login, please enable it and fill the user name, password and the server name.	

Figure 7.2.3.1 Dynamic IP Configuration

The screen contains the following details:

- Click APPLY to save the information that has been entered.
- Click CANCEL to exit from this page.

7.2.3.2 Static IP

To configure the WAN interface to use a Static IP Address, click on the Static IP link in the left navigation bar. A screen is displayed as shown in Figure 7.2.3.2.

	SYSTEM WA	N I LAN I NAT I EIREWALL ROUTE UPNP VDSL2 SUPPORT
 Dynamic IP IP Sattings IPFocE DNS 	IP Settings Fyour Service Provider has assigned a fixed	IP address, enter the assigned IP Address, Subnet Mask and ISP Gateway Address provided.
	P address assigned by your ISP Subnet Mask ISP Gateway Address	
	Does ISP provide more IP addresses	Tes .

Figure 7.2.3.2 Static IP Configuration

The screen contains the following details: Fields in Static IP

Field	Description
IP Address assigned by your ISP	Enter the IP Address of ALL126AM2/AS2.
Subnet Mask	Enter the Subnet Mask of ALL126AM2/AS2.

Fields in Static IP (cont'd)

Field	Description
ISP Gateway Address	Enter the Gateway address of the ALL126AM2/AS2.
Does ISP provide more IP	Provides more IP Addresses of the WAN interface.
Address	Select the check box to enable this option. A screen
	is displayed as shown in Figure 41. Click Add to add
	IP Address and Subnet Mask.

7.2.3.3 PPPoE

To configure the WAN interface to use PPPoE, click on the PPPoE link in the left navigation bar. A screen is displayed as shown in Figure 7.2.3.3.

	<u>SYSTEM</u>	<u>WAN</u> <u>LAN</u> <u>NAT</u> <u>FIREWALL</u> <u>ROUTE</u> <u>UPNP</u> <u>VDSL2</u> <u>SUPPORT</u>
→ Dynamic IP		
→ IP Settings	PPPOF	
→ PPPoE	TITOL	
→ DNS	Enter the PPPoE user name and password assigned by your Service Provider. The Service Name is normally optional, by may be required by some service providers. Enter a Maximum Idle Time (in minutes)to define a maximum period of time for which the Internet connection is maintained during inactivity. If the connection is inactive for longer than the defined Maximum Idle Time, then it will be dropped. You can enable the Auto-reconnect option to automatically re-establish the connection as soon as you attempt to access the Internet again. If your Internet Service Provider requires the use of PPPoE, enter the information below.	
	User Name	
	Password	
	Please retype your password	
	Service Name	
	MTU (1400-1492)	1492
	Maximum Idle Time	0 (minutes) 🗖 Auto-reconnect

Figure 7.2.3.3 PPPoE Configuration

The screen contains the following details:

Fields in PPPoE

Field

Description

User Name	Enter a name to use the PPPoE session.
Password	Enter the password of the login user.
Retype Password	Enter the password again to reconfirm.
Service Name	Enter a service name.
Fields in PPPoE (cont'd)	
Field	Description
MTU	Enter the maximum connection units of the PPPoE. The MTU range is 1400 to 1492 bytes. By default, it is 1492.
Maximum Idle Time	This is the period of time required to keep the connection alive if no packets are transmitted. If no packets are transmitted between LAN port and WAN port or between ALL126AM2/AS2 and WAN, the connection is disconnected after the 'Maximum idle time. If the Auto-reconnect check box is selected, the PPP connection is re-established if there is some data that is received from the upper layers to be transmitted on this link.

• Click CANCEL to exit from this page without saving the changes.

Click APPLY to save the information that has been entered.

7.2.3.4 DNS

To configure the DNS address, click on the DNS link in the left navigation bar. A screen is displayed as shown in Figure 7.2.3.4:

	SYSTEM	1 <u>WAN</u> <u>LAN</u>	NAT	FIREW	ALL	ROUTE	UPNP	VDSL2	SUPPOR	RT
→ Dynamic IP										
→ IP Settings	DNS									
→ PPPoE	DIVS									
→ DNS										
	Domain Nama Cantor				0.44		a 1			
	(DNS) Address		0	0	0	0				
	(Erro) maarooo									
	Secondary DNS Address (optional)		0	0	0	0				

Figure 7.2.3.4 DNS Configuration

The screen contains the following details:

Fields in DNS	
Field	Description
Domain Name Server(DNS) Address	Enter the DNS address of the primary DNS server.
Secondary DNS Address(optional)	Enter the address of the secondary DNS server, if
	available.

• Click CANCEL to exit from this page without saving the changes.

Click APPLY to save the information that has been entered.

7.2.4 LAN

The LAN Setting can be viewed in the left navigation bar. The following are the options available under LAN, as shown in Figure 7.2.4:

- LAN Settings
- DHCP Client List
- LAN Switch Port Setting
- LAN Port Status

		SYSTEM	WAN	LAN	NAT	FIREWALL	ROUTE	UPNP	VDSL2	SUPPORT
--	--	--------	-----	-----	-----	----------	-------	------	-------	---------

- → LAN Settings
- → DHCP Client List
- → LAN Switch Port Setting
- → LAN Port Status

Figure 7.2.4 LAN in Left Navigator Bar

7.2.4.1 LAN Settings

Attention: For the ALL126AM2/AS2 it is recommended to select a simple IP setting suitable to controlled lab environments. Set a static IP address and don't use DHCP. The required steps are explained in Chapter 4.4 on Page 13!

To configure the LAN interface, click on the LAN Settings link in the left navigation bar. A screen is displayed as shown in Figure 7.2.4.1 in case of the ALL126AM2/AS2.

	<u>SYSTEM WAN L</u>	AN NAT FIREWALL ROUTE UPNP VDSL2 SUPPORT
→ LAN Settings		
→ DHCP Client List	LAN Settings	
→ LAN Switch Port Setting	Entroctings	
→ LAN Port Status	You can enable DHCP to dynamically allocate IP a	addresses to your client PCs.
	IP Address	192 168 16 249
	Subnet Mask	255 255 0
	The Gateway acts as DHCP Server	Enable

Figure 7.2.4.1 LAN Settings

The screen contains the following details:

Fields in LAN Settings

Field	Description
IP Address	Enter the LAN interface IP Address of ALL126AM2/AS2.

Subr	net Mask				Enter the LAN Subnet Mask of ALL126AM2/AS2.
The	Gateway	acts	as	DHCP	Enable or disables the DHCP Server of the ALL126AM2/AS2.
Serv	er				Select the check-box to enable this option.

• Click CANCEL to exit from this page without saving the changes.

• Click APPLY to save the information that has been entered.

7.2.4.2 DHCP Client List

To view the DHCP client list, click on the DHCP Client List link in the left navigation bar. A screen is displayed to list all DHCP client connection with IP Address and MAC Address as shown in Figure 7.2.4.2.



Figure 7.2.4.2 DHCP Client List

7.2.4.3 LAN Switch Port Setting

To view the All Lan Port Setting, click on the All Lan Port Setting link in the left navigation bar. A screen is displayed to All Lan Port Setting as shown in Figure 7.2.4.3.

	<u>SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP VDSL2 SUPPORT</u>
→ LAN Settings	
→ DHCP Client List	All Lan Port Setting
→ LAN Switch Port Setting	
→ LAN Port Status	 The Lan Port Setting mode allows the user to specify the mode setting for the VDSL2 CO Modern. Users can choose 10Mb or 100Mb mode. Force 10Mb Full Auto 10/100 Full/Half Force 10Mb Half Force 100Mb Half Force 100Mb Full
	HELP APPLY CARCED

Figure 7.2.4.3 DHCP Client List

7.2.4.4 LAN Port Status The following information provides a view of the current Ethernet ports status of the unit

	SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP VDSL2 SUPPORT
→ LAN Settings	
→ DHCP Client List	Status
→ LAN Switch Port Setting	Status
→ LAN Port Status	The following information provides a view of the current Ethernet ports status of the unit
	Port 1
	Link Status Link Up, 100Mb/s, Full Duplex
	Port 2
	Link Status Link Down,
	Port 3
	Link Status Link Up, 100Mb/s, Full Duplex
	Port 4
	Link Status Link Down,

Figure 7.2.4.4 LAN Port Status

7.2.5 NAT The NAT Settings can be viewed in the left navigation bar. The following are the options available under NAT, as shown in Figure 7.2.5:

- Virtual Server
- Port Mapping
- DMZ

• •

•

	<u>SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP VDSL2 SU</u>	IPPOR
Virtual Server		
Port Mapping		
DMZ		

Figure 7.2.5 NAT in Left Navigator Bar

7.2.5.1 Virtual Server

To configure virtual server, click on the Virtual Server link in the left navigation bar. A screen is displayed as shown in Figure 7.2.5.1:

	SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP VOSL2 SUPPORT	
Virtual Server Port Mepping OMZ	Virtual Server	
	You can configure the Router as a virtual server so that remote users accessing nervices such as the Web or FTP atyour local service apublic IP ad automatically redirected to local servers configured with private IP addresses. In other words, depending on the requested service (TCP/LDP polt redirects the external service request to the appropriate server (located at another internal IP address).	iresses can be rumbers), the Router
	Private IP. Private Port Type Public Port Enabled	
	1 192.168.16. FTCP C UOP	
	2 192 166 16	
	3 192-168.16. F * TCP = UOP F	
	4 192 168 16. FTCP CLUDP TIL	
	5 192 168 16. F	

Figure 7.2.5.1 Virtual Server Configuration

The screen contains the following details:

Fields in Virtual Server

Field	Description
Private IP	Enter a private IP Address of specified entry.
Private Port	Enter a private Port number of the specified entry.
Туре	Select virtual server protocol type of the specified entry.
Public Port	Enter a public port number of the internet user to
	access the virtual server.
Enabled	Enable the specified entry of the virtual server.

• Click CANCEL to exit from this page without saving the changes.

• Click APPLY to save the information that has been entered.

7.2.5.2 Port Mapping

To configure Port Mapping, click on the Port Mapping link in the left navigation bar. A screen is displayed as shown in Figure 7.2.5.2:

		<u>SYSTEM WAN LAN NAT </u>	FIREWALL ROUTE UPNP VDSL2 SUPPORT	
 → Virtual Server → Port Mapping → DMZ 	Port Mapping			
	For some applications, you r user to configure the needed	need to assign a set or a range of I port mappings to suit such applic	ports to a specified local machine to route the packets. Router a ations	allows th
	Server IP	Mapping Ports	Enabled	
	1 192.168.16.			
	2 192.168.16.			
	3 192.168.16.			
	4 192.168.16.			
	5 192.168.16.			

Figure 7.2.5.2 Port Mapping Configuration

The screen contains the following details:

Fields in Port Mapping

Field	Description
Server IP	Enter the IP Address of a specified local machine.
Mapping Port	Assign a range of port or specific port number to route the packets.
Enabled	Enable a specified entry of the Port Mapping.

• Click CANCEL to exit from this page without saving the changes.

• Click APPLY to save the information that has been entered.

7.2.5.3 DMZ

To configure the DMZ, click on the DMZ link in the left navigation bar. A screen is displayed as shown in Figure 7.2.5.3:

	<u>SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP VDSL2 SUPPORT</u>
→ Virtual Server	
→ Port Mapping	DMZ(Demilitarized Zone)
→ DMZ	
	If you have a local client PC that cannot run an Internet application properly from behind the NAT firewall, you can open the client up to unrestricted two-way Internet access by defining a virtual DMZ Host.
	IP Address of Virtual DMZ Host 0 0 0 0

Figure 7.2.5.3 DMZ Configuration

The screen contains the following details:

Fields in DMZ

Field	Description	
Enable	Enable or disable the DMZ setting ALL126AM2/AS2. Select the check box to enab option.	g of le this
IP Address	Enter IP Address of the DMZ host.	

• Click CANCEL to exit from this page without saving the changes.

Click APPLY to save the information that has been entered.

The Firewall Settings can be viewed in the left navigation bar. The following are the options available under Firewall, as shown in Figure 7.2.6:

- Firewall Options
- Client Filter MAC Control
- MAC Control

	<u>SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP VDSL2 SUPPORT</u>
→ Firewall Options	
→ Client Filtering	
→ MAC Control	

Figure 7.2.6 Firewall in Left Navigator Bar

7.2.6.1 Firewall Options

To enable the firewall options, click on the Firewall Options link in the left navigation bar. A screen is displayed as shown in Figure 7.2.6.1:

	<u>SYSTEM WAN LA</u>	N NAT FIREWALL ROUTE UPNP VDSL2 SUPPORT
→ Firewall Options		
 → Client Filtering → MAC Control 	Block WAN Scan	
	"Block WAN Scan" allows you to prevent the hacke VDSL2 CO Modern to not respond to the hacker so	rs from testing the services of the VDSL2 CO Modern. "Discard ping from WAN side" cause the can packets from the public WAN IP address.
	Enable Hacker Attack Protect	
	Discard PING from WAN side	
	Discard to PING the Gateway	
	Drop Port Scan	

Figure 7.2.6.1 Firewall Options Configuration

The screen contains the following details:

Fields in Firewall Options

Field			Description
Enable	Hacker	Attack	Select the check box to log and drop all the hacker attack events.
Protect			
Discard P	ING from V	VAN	Select the check box to drop all PING from the WAN side.
Discard P	ING the Ga	ateway	Select the check box to drop all PING to ALL126AM2/AS2
			packet for the LAN side.
Drop Port	Scan		Select the check box to drop all the port scan packets.

• Click APPLY to save the information that has been entered.

7.2.6.2 Client Filter

To enable Client Filter, click on the Client Filter link in the left navigation bar. A screen is displayed as shown in Figure 7.2.6.2.

• Frewall Options • Client Filtering		SYSTEM WAN LAN NAT FIREWALI	I ROUTE UPNP YDSL2 SUPPORT		
 MAC Control 	Client Filter	ing			
	You can block o	ertain client ${\rm P}^{\rm c}{\rm Cs}$ accessing the Internet based on time.			
	🗹 Enable Cite	nt Filter			
		IP	Port	Type	Enable
	1	192.168.18.		P TCP C UDP	Γ
	2	192 168 16 -		# TCP C UDP	Π.
	3	192.168.16.	a.	C UDP	Ē
	4	192.168.16		# TCP C UDP	5
	5	192 168 16	~	ICP C UDP	E.
				6	200
				2	HELP APPLY CALLS

Figure 7.2.6.2 Client Filter Configuration

The screen contains the following details:

Fields in Client Filter

Field	Description
Enable Client Filter	Enable or disable the Client Filter feature of VDSL2 CO&CPE MODEM. Select the check box
	to enable this option.
IP	Enter the filter IP Address range of the local machines under VDSL2 CO&CPE MODEM.
Port	Enter the filter Port number range of the local machines under VDSL2 CO&CPE MODEM.
Туре	Select TCP or UDP to filter the protocol type packets from the local machines.
Enable	Provides more IP Addresses of the WAN interface.

• Click CANCEL to exit from this page without saving the changes.

• Click APPLY to save the information that has been entered.

7.2.6.3 MAC Control

To configure MAC Control, click on the MAC Control link in the left navigation bar. A screen is displayed as shown in Figure 7.2.6.3

	SYSTEM WAN	LAN NAT FIREWALL ROUTE UPNP VDSL2 SUPI	PORT	
→ Firewall Options				
→ MAC Control	MAC Control			
	You can block certain client PCs accessing the	Internet based on MAC addresses.		
	MAC Address Control :			
	MAC Address Control List			
	Block Connect to Internet	MAC Address		
			<< Add	
				200
				HELP APPLY CANCEL

Figure 7.2.6.3 MAC Control Configuration

The screen contains the following details:

Fields in MAC Control

Field	Description
MAC Address Control	Enable or disable the MAC address control.
Block Connection to Internet	Enable or disable block status. If the check box is selected, it blocks the specified MAC address.
MAC Address	Assign the blocking MAC address for local machine.

Click Add to add the specified MAC address entry in the list.

7.2.7 Route Settings

The Route Settings can be viewed in the left navigation bar. The following are the options available under Route, as shown in Figure 7.2.7:

- Static Rotuing
- Routing Table List

	SYSTEM 1	WAN LAN NAT FIREWALL ROUTE	UPNP VDSL2 SUPPORT	
 → Static Routing → Routing Table List 	Static Routing			
	The static routing function determines the different IP domain users to access the Inf	path that data follows over your network t ternet through this VDSL2 CO Modem de	before and after it passes through your re avice.	outer. You can use static routing to allow
	Destination LAN IP	Subnet Mask	Gateway	< Add

Figure 7.2.7 Route in Left Navigator Bar

7.2.7.1 Routing Table List

To view the Routing entry table list of ALL126AM2/AS2, click on the Routing Table by link in the left navigation bar. A screen is displayed as shown in Figure 7.2.7.1.

Static Routing		<u>3131EM</u>	MAN LAN NAT FIREWAL		PPORI	
→ Routing Table List	Routing Table					
	The Routing table all	ows you to see bow (many routings on your VDSL2	CO Modem routing table and int	erface information	
	The Rodeing table an		nany roatings on your +DOE2	co modern rousing table and me		
	Destination LAN IP	Subnet Mask	Gateway	Metric	Interface	efresh
	192.168.16.0	255.255.255.0	0.0.0.0	0	adm0	

Figure 7.2.7.1 Routing Table List

The screen contains the following details:

Click Refresh to update currently routing list of the ALL126AM2/AS2.

7.2.8 UPnP Setting

The UPnP Settings can be viewed in the left navigation bar. The following are the options available under UPnP, as shown in Figure 7.2.8:

To enable or disable the UPnP Settings, click on the Settings link in the left navigation bar.

A screen is displayed as shown in Figure 7.2.8.1.

<u>SYSTEM WAN LAN NAT FIREWALL ROUTE UPNP VDSL2 SUPPORT</u>		
→ Static Routing		
→ Routing Table List	UPnP Settings	
	UPnP is an architecture for pervasive peer-to-peer network connectivity of intelligent appliances, wireless devices, and PCs of all from factors. It is designed to bring easy-to-use, flexible, standards-based connectivity to ad-hoc or unmanaged networks whether in the home, in a small business, public spaces, or attached to the Internet. The supports the UPnP InternetGatewayDevice for Home Networking.	
	Enable UPnP	

Figure 7.2.8 / 7.2.8.1

The screen contains the following details:

Table 22 Fields in UPnP Settings

Field	Description
Enable UpnP	To enable or disable UPnP Setting. Select the check box to Enable or Disable the UPnP function of SPEED-VDSL2 CO&CP MODEM.

- Click CANCEL to exit from this page without saving the changes.
- Click APPLY at any time during configuration to save the information that you have entered.

Appendix A: Product Features & Specification

Product Name ALL126AM2/AS2 (VDSL2 Modem)

Features:

- Compliant with IEEE 802.3 & 802.3u Ethernet Standards
- Compliant with ETSI, ITU, ANSI VDSL standards
- Provides 4 x 10/100M auto-sensing RJ-45 Ethernet ports
- Supports Bandwidth setup with 100 Mbps VDSL RJ-11 ports
- POTS / ISDN Splitter port RJ-11 x 1 (Splitter on board)
- Supports auto speed for VDSL2 port
- Supports Web management(HTTP)
- Supports TFTP
- Supports PPPOE
- Supports NAT/DHCP/DMZ
- Supports Firewall
- Supports Route & Switch mode
- Supports UPnP
- Supports Loop back
- Supports SNR indicator
- Provides surge protection for VDSL2 port

Specifications:

- Compliant with IEEE 802.3 & 802.3u Ethernet Standards
- Compliant with ETSI, ITU, ANSI VDSL2 standards
- 10/100M auto-sensing/auto-MDIX RJ-45 Ethernet ports x 4
- VDSL2 RJ-11 port x 1 (ALL126AM2 for CO / ALL126AS2 for CPE)
- POTS / ISDN Splitter port RJ-11 x 1
- Switch method : store and forward
- Flow control Full duplex : IEEE 802.3x
 - Half duplex : Back pressure
- Driver capable : 100 M: 0.3 Km
- Indication LED x 6: Power LED x1 Ethernet Link/Active LED x 4
 - VDSL Link LED x 1
- Console port : RS-232C/115200bps
- Dimension: L x W x H = 184mm x 146mm x 40mm(7.2" x 5.74" x 1.57")
- Operating temperature: 0℃ to 50℃ (32 to 122F)
- Operating humidity: 10% to 90% (non-condensing)
- Storage temperature: -20 to 65℃ (-4F to 149F)
- AC to DC adapter Input range: 100VAC~240VAC/50~60Hz Output: 12VDC/1A
- Power consumption : 7.5w
- EMI Compliant: CE, FCC, VCCI
- Chipset: Infineon

Appendix B: Troubleshooting

- 1. **Symptom**: Connected the Co-Modem with CPE-Modem within 300 meters RJ-11 phonecable got only less than 10 Mbit/s.
 - **Cause**: Some testing program which is base on TCP/IP protocol such as FTP, Iperf, NetIQ, the bandwidth of testing outcome will be limited by TCP window size.
 - **Solution**: We recommand to test VDSL2 bandwidth best by Smartbit equipment, if you don't have Smartbit, we recommand test that by IPERF program, and TCP window size must be setted max. 64k, the parameter as iperf –c co side ip address–I 1 –t 50 –w 65535 for client side.

Appendix C Compliance and Safety Information

FCC Radio Frequency Interference Statement

This equipment has been tested to comply with the limits for a computing device, pursuant to Part 15 of FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment can generate, use and radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by taking one or more of the following measures

1. Reorient or relocate the receiving antenna.

2.Increase the distance between the equipment and receiver.

3. The equipment and the receiver should be connected to outlets on separate circuits.

4.Consult the dealer or an experienced radio/television technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

If this telephone equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the proper functioning of your equipment. If they do, you will be notified in advance in order for you to make necessary modifications to maintain uninterrupted service.

This equipment may not be used on coin service provided by the telephone company. Connection to party lines is subject to state tariffs.

Important Safety Instructions

Caution The direct plug-in wall transformer serves as the main product for disconnecting. The socket outlet shall be installed near the product and be readily accessible.

Caution Use only the power supply included with this product. In the event the power supply is lost or damaged In the United States, use only with CSA certified or UL listed Class 2 power supply, rated 12Vdc 1A or above.

IN Europe, use only with CE certified power supply, rated 12Vdc 1A or above.

Do not use this equipment near water, for example in a wet basement.

Avoid using a telephone during an electrical storm. There may be a remote risk of electrical shock from lightning. Do not use the telephone to report a gas leak in the vicinity of the leaking area.

If you experience trouble with this unit, please contact customer service at the address and phone listed below. DO NOT DISASSEMBLE THIS EQUIPMENT. It does not contain any user serviceable components.

FCC Warning

This equipment has been tested to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment can generate, use, and radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at owner's expense.

CE Mark Warning

This is a CE class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

Warranty

The original owner of this package will be free from defects in material and workmanship for one-year parts after purchase. For the warranty to apply, you must register your purchase by returning the registration card indicating the date of purchase.

There will be a minimal charge to replace consumable components, such as fuses, power transformers, and mechanical cooling devices. The warranty will not apply to any products which have been subjected to any misuse, neglect or accidental damage, or which contain defects which are in any way attributable to improper installation or to alteration or repairs made or performed by any person not under control of the original owner.

The above warranty is in lieu of any other warranty, whether express, implied, or statutory, including but not limited to any warranty of merchantability, fitness for a particular purpose, or any warranty arising out of any proposal, specification, or sample. Shall not be liable for incidental or consequential damages. We neither assumes nor authorizes any person to assume for it any other liability.

Note: Please do not tear off or remove the warranty sticker as shown, otherwise the warranty will be void.

WARNING Warranty Void If Removed

CE-Kennzeichnung und EG-Konformitätserlärung

Für das folgend bezeichnete Erzeugnis

ALL126AM2 VDSL2 Master-Modem

ALLNET PartNr. 63905



CE-Kennzeichnung

Wird hiermit bestätigt, dass es den Anforderungen entspricht, die in der Richtlinie des Rates zur Angleichung der Rechtsvorschriften der Mitgliedstaaten über die elektromagnetische Verträglichkeit (89/336/EWG) festgelegt sind.

Zur Beurteilung des Erzeugnisses hinsichtlich elektromagnetischer Verträglichkeit wurden folgende Normen herangezogen:

EN 55022: 1998 + A1: 2000 + A2: 2003, Class A

EN 61000-3-2: 2000 EN 61000-3-3: 1995 + A1:2001 EN 55024: 1998 + A1:2001 IEC 61000-4-2 1995 + A1: 1998 + A2: 2000 IEC 61000-4-3 2002 + A1: 2002 IEC 61000-4-4 1995 + A1: 2000 + A2: 2001 IEC 61000-4-5 1995 + A1: 2000 IEC 61000-4-6 1996 + A1: 2000 IEC 61000-4-8 1993 + A1: 2000 IEC 61000-4-11 1994 + A1: 2000

Diese Erklärung wird verantwortlich für den Hersteller/Bevollmächtigten abgegeben:

ALLNET Computersysteme GmbH Maistr. 2 82110 Germering

CE-Kennzeichnung und EG-Konformitätserlärung

Für das folgend bezeichnete Erzeugnis

ALL126AS2 VDSL2 Client-Modem

ALLNET PartNr. 63906



CE-Kennzeichnung

Wird hiermit bestätigt, dass es den Anforderungen entspricht, die in der Richtlinie des Rates zur Angleichung der Rechtsvorschriften der Mitgliedstaaten über die elektromagnetische Verträglichkeit (89/336/EWG) festgelegt sind.

Zur Beurteilung des Erzeugnisses hinsichtlich elektromagnetischer Verträglichkeit wurden folgende Normen herangezogen:

EN 55022: 1998 + A1: 2000 + A2: 2003, Class A

EN 61000-3-2: 2000 EN 61000-3-3: 1995 + A1:2001 EN 55024: 1998 + A1:2001 IEC 61000-4-2 1995 + A1: 1998 + A2: 2000 IEC 61000-4-3 2002 + A1: 2002 IEC 61000-4-4 1995 + A1: 2000 + A2: 2001 IEC 61000-4-5 1995 + A1: 2000 IEC 61000-4-6 1996 + A1: 2000 IEC 61000-4-8 1993 + A1: 2000 IEC 61000-4-11 1994 + A1: 2000

Diese Erklärung wird verantwortlich für den Hersteller/Bevollmächtigten abgegeben:

ALLNET Computersysteme GmbH Maistr. 2 82110 Germering
ERKLÄRUNG ZUR VERWENDUNG VON GPL-LIZENSIERTER SOFTWARE IN ALLNET-PRODUKTEN

Im vorliegenden Produkt wurden Teile von Linux sowie des netfilter/iptables Projektes (www.netfilter.org), die unter der GPL (General Public Licence, (http://www.gnu.org/home.de.html) lizensiert wurden, implementiert. Den Source Code, welcher in dem Produkt verwendet wurde, können Sie auf unserer Website www.allnet.de im Downloadbereich herunterladen.

Ihre Allnet Deutschland GmbH

ALLNET GmbH Maistraße 2 82110 Germering

Tel.: 089 / 894 222 22 Fax: 089 / 894 222 33

sales@allnet.de www.allnet.de

Achtung:

Bitte beachten sie, dass durch Modifikation der Firmware eines Allnet-Geräts die Garantie auf dieses Gerät verloren geht. Alle Veränderungen an der Firmware geschehen also auf ihr eigenes Risiko, da dieses Gerät dann im Fehlerfall nicht umgetauscht oder sonstwie ersetzt werden kann.

VDSL2 Modem ALL126AM2 (CO) / ALL126AS2 (CPE) USER'S MANUAL

DISCLAIMER FOR ALLNET-PRODUCTS WHICH CONTAIN GPL-LICENSED SOFTWARE

The Allnet-product you have bought is using Linux software and parts of the netfilter/iptables-project. (www.netfilter.org), which both are licensed using the GPL (General Public License, available for download at www.gnu.org/home.de.html).

You can download the complete source-code of this product at www.allnet.de in the download-area for this model.

ALLNET GmbH Maistraße 2 82110 Germering

Tel.: +49 89 / 894 222 22 Fax: +49 89 / 894 222 33

sales@allnet.de www.allnet.de

Attention:

Please be aware that any modifications of the firmware for this device will void the warranty. All modifications will be on your own risk and, in case of any damage to the device, Allnet can not repair or replace the device free of charge.