

Quick Installation Guide



ALL-SG4816CW

Default Values:

IP-Adresse: 192.168.2.1 Passwort: admin
--

Assign your PC an IP address by subnet 192.168.1.X (**X = 2-254**) with subnet mask 255.225.225.0

Start your browser and type the address 192.168.1.1 into the browser address field, confirm the IP address with enter.

Login Password = **admin**

A screenshot of a web-based login interface. It has a dark gray background with rounded corners. At the top left, the word "LOGIN" is displayed in white capital letters. Below it, the label "Password:" is followed by a white rectangular input field. To the right of the input field is a light gray button with the word "Apply" in dark gray text.

RESET DEVICE TO FACTORY DEFAULT:

Press the reset button for 30 seconds.

Afterwards the device will reboot with factory default.



CE-Declaration of Conformity

For the following equipment:

Germering, 1st of June, 2014

Smart managed 16 Port Gigabit/Combo + 2x SFP Switch

ALL-SG4816CW



The safety advice in the documentation accompanying the products shall be obeyed.
The conformity to the above directive is indicated by the CE sign on the device.

The ALLNET ALL-SG4816CW conforms to the Council Directives of 2004/108/EC.

This equipment meets the following conformance standards:

EN55022:2010: Class A

IEC61000-3-2:2005+A1:2008+A2:2009

IEC61000-3-3:2008

EN55024:2010

IEC61000-4-2:2008

IEC61000-4-3:2006+A1:2007+A2:2010

IEC61000-4-4:2004+A1:2010 IEC61000-4-5:2005

IEC61000-4-6:2008

IEC61000-4-8:2009

IEC61000-4-11:2004

This equipment is intended to be operated in all countries.

This declaration is made by
ALLNET GmbH Computersysteme
Maistraße 2
82110 Germering
Germany

Germering, 01.06.2014



Wolfgang Marcus Bauer
CEO