Introduction

Thank you for purchasing the **USB 2.0 VGA Adapter**. The USB 2.0 VGA Adapter enables you to connect any monitor, LCD, projector to your PC or notebook. You can use it as an extended desktop or as a larger/different display for you main screen. By using USB 2.0 technology, there is no need to open the computer or struggle with compatibility issues related to a second VGA card.

What are the benefits and uses?

Office workstation:

- View your large spreadsheets across two screens with display continuity
- Multitask more effectively without overlapping windows
- Open attachments on one screen while reading the e-mail on the other

On the road:

- Do multiple screen displays and presentations without bringing another computer

Graphics workstation:

- Use second display for pallets/tools

Editing workstation:

- Type documents on one screen while viewing reference material on the other

Wall Street:

- Use a notebook for viewing multiple screens
- View charts and live data at the same time

Entertainment:

- View videos/TV on one screen and reviews on the other

How will YOU use it?

System Requirements

Available USB 2.0 port Windows 2000/XP operating system.

Package Contents

USB 2.0 VGA Adapter x 1 Driver/Manual CD x 1 (Driver version : 5.4.2.0831.0101H)

Quick installation

Follow these steps to quickly install your new USB 2.0 VGA Adapter:

NOTE:

Do not plug the USB 2.0 VGA adapter into the system before the driver is finished installing.

- 1. Insert the driver/manual CD and follow the instructions.
- 2. Make sure to restart the computer.
- 3. Turn on your 2nd monitor and connect it to the adapters.
- 4. Plug the adapter into an available **USB 2.0 port**.
- 5. After complete, you should see the extended display on the 2nd monitors.

See Appendix for detail instruction of the driver installation, Frequently Asked Questions and

Troubleshooting Tips sections for additional help.

Display Utility

After the driver is installed, a utility will appear in the lower right taskbar. This utility allows you to quickly change the settings and resolution for your USB 2.0 VGA Adapter. Access the menu by right clicking on the icon.



Support Function :

- 1. Primary
- 2. Extended
- 3. Mirror

Support Resolution :

Resolution	Color Bits
1280 * 1024	8,16
1280 * 768	8 , 16 , 32
1152 * 864	8 , 16 , 32
1024 * 768	8 , 16 , 32
800 * 600	8 , 16 , 32
640 * 480	8 , 16 , 32

USB-VGA (Primary)

Make the USB 2.0 VGA Adapter the main display adapter in the system. The system's main display adapter (and monitor) will automatically switch to being the secondary display adapter and act as the extended desktop. Note: Some display utility and drivers that ship with AGP and built-in display adapters will prevent this option from working on some systems. You can disable the other utility (usually found in the same toolbar located on the bottom right hand corner) to make this function work properly.

✓ USB-VGA (Primary) USB-VGA (Extended) USB-VGA (Off) Mirror			
Resolution	640X480X8 610X180X16 640X480X32		
	800X600X8 800X600X16	1152X864X8 1152X864X16 1152X864X32	
	1024X768X8 1024X768X16	1280X768X8 1280X768X16 1280X768X32	
	1024X768X32 High Resolution 🔸	1280X1024X8 ✓ 1280X1024X16	
			<mark>۷</mark>

USB-VGA (Extended)

By default, your USB 2.0 VGA Adapter will extend your Windows desktop.

You can change the relative position of this extension under the **Display Properties**. See instructions located later in the manual.

	640X480X8 640X480X16 640X480X32	1152X864X8	
	800X600X8 800X600X16	1152X864X16 1152X864X32	
USB-VGA (Primary) USB-VGA (Extended) USB-VGA (Off)	1024X768X8 1024X768X16	1280X768X8 1280X768X16 1280X768X32	
Mirror Resolution	1024x768X32 High Resolution 🔸	1280X1024X8 1280X1024X16 	4 7 🗞

Mirror

Your USB 2.0 VGA Adapter will mirror your Windows desktop. You can see the same desktop image in another monitor.

	640X480X8 640X480X16 640X480X32	1152X864X8	
	800X600X8 800X600X16	1152X864X16 1152X864X32	
USB-VGA (Primary) USB-VGA (Extended) USB-VGA (Off)	1024X768X8 1024X768X16	1280X768X8 1280X768X16 1280X768X32	
Mirror Resolution	1024X768X32 High Resolution 🔸	1280X1024X8	u 3 8

USB-VGA (Off)

This option disables the USB 2.0 VGA Adapter on the system.



USB 2.0 VGA Adapter Properties

To access the Display Properties for the USB 2.0 VGA Adapter, go to "**Control Panel**" and double click on the "**Display**" icon. Select the "**Settings**" tab.

Click on the "Display" pull down menu and select the "USB 2.0 VGA DEVICE".

From here, you can change the resolution and color depth as desired.

Click "**OK**" to apply the settings.

You can also make these changes using the USB 2.0 VGA Adapter utility.

	ropertie	S			?
Themes	Desktop	Screen Saver	Appearance	Settings	
Drag th	e monitor ic	ons to match th	e physical arran	igement of yo	our monitors.
		0			
		2			
				21	
<u>D</u> isplay:					
-					
2. (Def	ault Monito	r) on USB2.0 V0	A DEVICE(D S	PLAY).	~
2. (Del 1. Plug	iault Monito 1 and Play M	r) on USB2.0 V0 1onitor on SiS 31	GA DEVICE(D S 00/305/630/54	(PLAY). 10/730	~
2. (Del 1. Plug 2. (Def Less	fault Monito I and Play M ault Monitor	r) on USB2.0 VC 1onitor on SiS 31 r) on US32.0 VC More	GA DEVICE(D S D0/305/630/54 GA DEVICE(DIS History	(730 PLAY). 10/730 PLAY).	~
2. (Del 1. Plug 2. (Def Less	fault Monito I and Play M ault Monitor	r) on USB2.0 V0 1onitor on SiS 30 () on US32.0 V0 More	GA DEVICE(D S 00/305/630/54 iA DEVICE/DIS Highest	6PLAY). 10/730 PLAY). (32 bit)	~
2. (Del 1. Plug 2. (Def Less	fault Monito and Play M ault Monitor 1024 by 7	r) on USB2.0 VC 1onitor on SiS 30 (1 on USB2.0 VC More 68 pixel:	6A DEVICE(D S 00/305/630/54 A DEVICE(DIS Highest	;PLAY). :0/730 :PLAY). (32 bit)	~
2. (Del 1. Plug 2. (Def Less	fault Monito and Play M ault Monitor 1024 by 7 this device	r) on USB2.0 V0 1 on US32.0 V0 More 68 pixels as the primary r	6A DEVICE(D S 00/305/630/54 iA DEVICE/DIS Highest	iPLAY). 10/730 PLAY). (32 bit)	×
2. (Del 1. Plug 2. (Def 2. (Def Less 	fault Monito and Play M ault Monitor 1024 by 7 this device and my Wine	r) on USB2.0 V0 1 on USB2.0 V0 1 on USB2.0 V0 More 68 pixels as the primary r dows desktop o	6A DEVICE(D S 00/305/630/54 A DEVICE(DIS Highest nonitor. nto this monitor.	iPLAY). 10/730 IPLAY). (32 bit)	
2. (Del 1. Plug 2. (Def Less 	fault Monito and Play M ault Monitor 1024 by 7 this device and my Wind	r) on USB2.0 V0 fonitor on SiS 31 (1 on US32.0 V0 More 68 pixels as the primary r dows desktop o	6A DEVICE(D S 00/305/630/54 A DEVICE/DIS Highest nonitor. nto this monitor.	iPLAY). 10/730 PLAY). (32 bit)	
2. (Del 1. Plug 2. (Def 2. (Def L€SS 	fault Monito and Play M ault Monitor 1024 by 7 this device and my Wind	r) on USB2.0 V0 fonitor on SiS 30 (1 on USB2.0 V1 More 68 pixels as the primary r dows desktop o	6A DEVICE(D S 00/305/630/54 A DEVICE(DIS Highest nonitor. nto this monitor. <u>I</u> roublesh	iPLAY). 10/730 IPLAY). (32 bit)	Ad <u>v</u> anced
2. (Del 1. Plug 2. (Def Less 	fault Monito and Play M ault Monito 1024 by 7 this device and my Wind	r) on USB2.0 V0 fonitor on SiS 31 (1 on USB2.0 V0 More 68 pixels as the primary r dows desktop o	A DEVICE(D S 00/305/630/54 A DEVICE/DIS Highest nonitor. nto this monitor.	iPLAY). 10/730 (700 PLAY). (32 bit)	Ad <u>v</u> anced

Virtual Repositioning Your Displays

On the Settings tab of your Display Properties, click and drag the appropriate monitor icon (labeled 1 or 2) to the desired position. For example, the secondary display can be dragged to the left of the primary display, allowing it to be virtually on the left. Click **OK** or **Apply** to save the changes.

Appendix --- Driver Installation Procedure

ep 1 : Execute the Setup.exe from the CD driver, and click " Next ".		
USB 2.0 VGA Adapter Driver Install		
	Welcome to the InstallShield Wizard for USB 2.0 VGA Adapter	
	The InstallShield® Wizard will install USB 2.0 VGA Adapter on your computer. To continue, click Next.	
< <u>B</u> ack (<u>Next</u> >) Cancel		



Frequently Asked Questions (FAQ)

Q: Why can I not make the USB 2.0 to VGA Adapter the primary display? **A:** Some video cards ship their product with a utility that prevent other video cards from being set as the primary card. Check the bottom right hand corner taskbar for the utility. Disable the utility before switching our adapter to be the primary display.

Q: Why will my DVD player not work when I move it over to the extended display? **A:** Some DVD playback software packages do not support playing on a second display adapter of any kind.

Q: How come my video will not play on Media Player if I move it over to the extended desktop?

A: Check that you have moved the Media Player window completely over to the second screen.

Q: Why does my mouse not move pass the right side of the screen as it should on extended desktop?

A: Check the display settings and make sure that your display number '2' is on the right side of display number '1'. You can rearrange how Windows treats each display in relation to each other in the Display Properties Settings.

Q: There are lines running horizontally up and down my screen.

A: This is due to a low refresh rate setting. You can change this in the Display Properties Settings Advanced Monitor. Make sure you select the USB 2.0 VGA Device first and not set the refresh rate higher than what your monitor can support. This may damage your monitor. You can also try to reset/refresh/resynchronize your monitor.

Q: Direct3D does not work?

A: This is a current limitation of the adapter. Please check for driver updates in the future to add support for this. If your application requires this, please use the main display adapter.

Troubleshooting Tips

The following troubleshooting tips may help if you are experiencing any issues. Contact your dealer for additional help if needed.

- Check to make sure that all connectors are plugged in correctly.
- Make sure that the USB port that you are using is USB 2.0.
- Check to see that the monitor is connected correctly and the power is ON.
- Try connecting the adapter directly to the computer instead of through a hub.
- Unplug all other USB devices from the system.
- Make sure you restart your computer after the driver installation.
- Unplug the adapter and re-insert it.
- Try a different USB 2.0 port and/or computer
- Check the website to make sure you have the latest drivers.
- Reset/refresh/resynchronize your monitor.
- If you have problems during the boot up process, start your computer in Safe Mode and uninstall the driver. Hold the CTRL key until the Windows startup menu appears and select Safe Mode.

Copyright© 2005

All other company and/or products names are trademarks and/or registered trademarks of their respective owners. Features, performance and specifications are subject to change without notice. Product may not be exactly as shown in the diagrams.